



SYNC HD™

Firmware Version 2.1.1



Legal Notices

This guide is copyrighted ©2007 by Digidesign, a division of Avid Technology, Inc. (hereafter "Digidesign"), with all rights reserved. Under copyright laws, this guide may not be duplicated in whole or in part without the written consent of Digidesign.

003, 003 Rack, 96 I/O, 96i I/O, 192 Digital I/O, 192 I/O, 888|24 I/O, 882|20 I/O, 1622 I/O, 24-Bit ADAT Bridge I/O, AudioSuite, Avid, Avid DNA, Avid Mojo, Avid Unity, Avid Unity ISIS, Avid Unity MediaNetwork, Avid Xpress, AVoption, AVoption|V10, Beat Detective, Bruno, Command|8, Control|24, D-Command, D-Control, D-Fi, D-fx, D-Show, DAE, Digi 002, Digi 002 Rack, DigiBase, DigiDelivery, Digidesign, Digidesign Audio Engine, Digidesign Intelligent Noise Reduction, Digidesign TDM Bus, DigiDrive, DigiRack, DigiTest, DigiTranslator, DINR, DV Toolkit, EditPack, Impact, Interplay, M-Audio, MachineControl, Maxim, Mbox, MediaComposer, MIDI I/O, MIX, MultiShell, OMF, OMF Interchange, PRE, ProControl, Pro Tools M-Powered, Pro Tools, Pro Tools|HD, Pro Tools LE, QuickPunch, Reel Tape, Reso, Reverb One, ReVibe, RTAS, Smack!, SoundReplacer, Sound Designer II, Strike, Structure, SYNC HD, SYNC I/O, Synchronic, TL Space, Velvet, and X-Form are trademarks or registered trademarks of Digidesign and/or Avid Technology, Inc. All other trademarks are the property of their respective owners.

Product features, specifications, system requirements, and availability are subject to change without notice.

PN 9106-56838-00 REV A 08/07

Comments or suggestions regarding our documentation?
email: techpubs@digidesign.com

WARNING: This product contains chemicals, including lead, known to the State of California to cause cancer and birth defects or other reproductive harm. Wash hands after handling.

Communications & Safety Regulation Information

Compliance Statement

The model SYNC HD complies with the following standards regulating interference and EMC:

- FCC Part 15 Class A
- EN55103 – 1, environment E4
- EN55103 – 2, environment E4
- AS/NZS 3548 Class A
- CISPR 22 Class A

Radio and Television Interference

This equipment has been tested and found to comply with the limits for a Class A digital device, pursuant to Part 15 of the FCC Rules.

DECLARATION OF CONFORMITY

We, Digidesign,
2001 Junipero Serra Blvd.
Daly City, California 94014-3886, USA
650-731-6100
declare under our sole responsibility that the product
SYNC HD
complies with Part 15 of FCC Rules.

Operation is subject to the following two conditions: (1) this device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

Communications Statement

NOTE: This equipment has been tested and found to comply with the limits for a Class A digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference when the equipment is operated in a commercial environment. This equipment generates, uses, and can radiate radio frequency energy and, if not installed and used in accordance with the instruction manual, may cause harmful interference to radio communications. Operation of this equipment in a residential area is likely to cause harmful interference in which case the user will be required to correct the interference at his own expense.


Changes or modifications to this product not authorized by Digidesign, Inc., could void the Certification and negate your authority to operate the product.

Canadian Compliance Statement:

This Class A digital apparatus complies with Canadian ICES-003

Cet appareil numérique de la classe A est conforme à la norme NMB-003 du Canada

Australian Compliance



European Compliance



Safety Statement

This equipment has been tested to comply with USA and Canadian safety certification in accordance with the specifications of UL Standards: UL60065 7th /IEC 60065 7th and Canadian CAN/CSA C22.2 60065:03. Digidesign Inc., has been authorized to apply the appropriate UL & CUL mark on its compliant equipment.

Warning



Important Safety Instructions

- 1) Read these instructions.
- 2) Keep these instructions.
- 3) Heed all warnings.
- 4) Follow all instructions.
- 5) Do not use this apparatus near water.
- 6) Clean only with dry cloth.
- 7) Do not block any ventilation openings. Install in accordance with the manufacturer's instructions.
- 8) Do not install near any heat sources such as radiators, heat registers, stoves, or other apparatus (including amplifiers) that produce heat.
- 9) Do not defeat the safety purpose of the polarized or grounding-type plug. A polarized plug has two blades with one wider than the other. A grounding type plug has two blades and a third grounding prong. The wide blade or the third prong are provided for your safety. If the provided plug does not fit into your outlet, consult an electrician for replacement of the obsolete outlet.
- 10) Protect the power cord from being walked on or pinched particularly at plugs, convenience receptacles, and the point where they exit from the apparatus.
- 11) Only use attachments/accessories specified by the manufacturer.
- 12) Use caution when replacing the Lithium battery in the FOH Rack unit. There is danger of explosion if battery is incorrectly replaced. Replace only with the same or equivalent type.
- 13) Unplug this apparatus during lightning storms or when unused for long periods of time.
- 14) Refer all servicing to qualified service personnel. Servicing is required when the apparatus has been damaged in any way, such as power-supply cord or plug is damaged, liquid has been spilled or objects have fallen into the apparatus, the apparatus has been exposed to rain or moisture, does not operate normally, or has been dropped.

contents

| | |
|---|----|
| Chapter 1. Introduction | 1 |
| SYNC HD Features | 2 |
| System Requirements | 3 |
| Digidesign Registration | 3 |
| About the Pro Tools Guides | 4 |
| About www.digidesign.com | 5 |
| | |
| Chapter 2. Installation and Configuration | 7 |
| Hardware Connections | 7 |
| MachineControl | 9 |
| Synchronization and Time Code Connections to Machines, Decks, and Other Devices | 10 |
| Software Installation | 12 |
| Configuring the Device ID | 13 |
| Configuring the SYNC HD from Pro Tools HD | 14 |
| MachineControl Configuration | 21 |
| Software Configuration for the SYNC Setup Software Utility | 21 |
| Troubleshooting | 22 |
| | |
| Chapter 3. SYNC HD Hardware and Software | 23 |
| SYNC HD Front Panel | 23 |
| SYNC HD Back Panel | 26 |
| SYNC Setup Software Utility | 28 |
| | |
| Chapter 4. Using SYNC HD | 33 |
| SYNC HD Controls in Pro Tools, SYNC Setup Software Utility, and the SYNC HD Front Panel ... | 34 |
| Front Panel Generator/Parameter Switches | 35 |
| Clock References and Options | 36 |
| Positional Reference and Options | 43 |
| Compensating for Time Code Offsets | 49 |

| | |
|---|-----------|
| Generating & Regenerating Time Code | 49 |
| Generating a Window Dub. | 57 |
| Chapter 5. Additional Operational Information | 59 |
| Front Panel Generator/Parameter Controls | 59 |
| Using Fader Start | 64 |
| Calibrating the SYNC HD Oscillator. | 65 |
| Restoring Factory Settings. | 66 |
| Managing and Selecting Video Inputs. | 67 |
| Appendix A. Additional Synchronization Information | 69 |
| Video and VITC Signals | 69 |
| LTC Signals | 70 |
| Auto-Switch LTC/VITC | 70 |
| Digital Clock Signal Types | 71 |
| Bi-Phase/Tach | 72 |
| Pilot Tone | 73 |
| Appendix B. Technical Specifications | 75 |
| Appendix C. Wiring Diagrams and Pin Assignments. | 83 |
| LTC Connectors | 83 |
| Bi-Phase/GPI/Pilot Pin Diagram | 84 |
| Bi-phase/Tach OptoCoupler Input. | 85 |
| GPI Relay Outputs | 86 |
| GPI (TTL)/MTC Outputs | 87 |
| GPI (opto) Inputs | 88 |
| Connector Pin Assignments. | 89 |
| SYNC HD Cable Pin Assignments | 91 |
| Bi-phase/Tach/GPI/Pilot Port Interfacing Notes | 92 |
| Index | 93 |

chapter 1

Introduction

Welcome to the Digidesign SYNC HD, a multi-purpose synchronization peripheral for Pro Tools HD systems. The SYNC HD supports all Pro Tools sample rates, and synchronizes to most major time code and clock reference standards used in audio, video, film, and multimedia production.

The SYNC HD can also be used as a standalone synchronization device.

SYNC HD with Pro Tools|HD Systems

With a Pro Tools|HD system, the SYNC HD provides highly accurate lock to time code. Most SYNC HD settings are available directly from within Pro Tools.

SYNC HD in Standalone Mode

The SYNC HD can be used as a standalone synchronization converter, time code generator, clock generator and time code character generator. Throughout this guide, the term *standalone* refers to systems using the SYNC HD but *not* using Pro Tools. When used as a standalone device (known as “Standalone mode”), the SYNC HD is connected to time code or clock signals, and is configured from the front panel.

Optionally, while in Standalone mode, the SYNC HD can be controlled remotely from a Windows computer using the SYNC Setup software utility.

SYNC Setup Software Utility (Windows Only)

The SYNC Setup software utility can be used with or without Pro Tools to control all SYNC HD features from any supported Windows computer.

SYNC HD Features

The SYNC HD supports all Pro Tools HD sample rates (44.1, 48, 88.2, 96, 176.4, and 192 kHz) and supports industry standard SD (standard definition) and HD (high-definition) video reference rates. The SYNC HD provides the following features with Pro Tools HD:

Supported Positional Reference Sources

- LTC
- VITC
- Bi-phase/Tach
- Internal Time Code Generator
- Serial Time Code

Supported Clock Reference Sources

- Loop Sync
- Reference Video (SD and HD rates)
- Composite Video Input
- Word Clock
- AES/EBU DARS
- Pilot Tone
- Internal Crystal
- Bi-phase/Tach
- LTC

Output and Generation

- Loop Sync
- Digidesign Super Clock (256x sample clock)
- Word Clock (1x sample clock)
- AES/EBU null clock (AES “digital black”)
- VITC (if a video input is present)
- LTC
- MIDI Time Code (MTC)
- Two 9-pin Sony P-2 protocol ports, for limited serial deck control with MachineControl-enabled systems

Other Features

- SYNC I/O Emulation for legacy software support
- Front panel controls and a large LED display of time code and parameters
- Integrated control of the SYNC HD from Pro Tools
- Time Code Character Generator
- Fader start, provided through GPI output, for remote transport control from select Pro Tools fader movement
- SYNC Setup software utility (Windows only)
- Field-updatable firmware

Available Controls in Standalone Mode

If you are using the SYNC HD in Standalone mode, you can control it with the SYNC Setup software utility (Windows only), or with the switches on the front panel of the SYNC HD.

SYNC Setup Software Utility

(Windows Only)

The SYNC Setup software utility gives you access to all SYNC HD controls. The following SYNC HD parameters are accessible only through Pro Tools or the SYNC Setup software utility:

- Variable Speed Override (VSO)
- Window burn parameters: While you can turn the Window burn on or off from the front panel, you cannot configure its display parameters without Pro Tools or the SYNC Setup software utility.



See “SYNC HD Controls in Pro Tools, SYNC Setup Software Utility, and the SYNC HD Front Panel” on page 34.

System Requirements

Compatibility Information


Digidesign can only assure compatibility and provide support for hardware and software it has tested and approved.

For a list of Digidesign-qualified computers, operating systems, hard drives, machine controllers and third-party devices, visit the Digidesign website (www.digidesign.com).

SYNC HD with Pro Tools

To use the SYNC HD with Pro Tools HD, the following is required:

- A Digidesign-qualified Pro Tools|HD system
- An available DigiSerial port on the system's HD Core card
- An 8-pin to 8-pin serial cable (included) to connect the SYNC HD to the DigiSerial port on a Pro Tools PCI or PCIe card

 *If you use a custom serial cable between Pro Tools and the SYNC HD, be sure the cable supports hardware handshaking.*

The maximum supported length for this cable is 100 ft.

For more information, see Appendix C, "Wiring Diagrams and Pin Assignments."


For complete system requirements, visit the Digidesign website (www.digidesign.com).

SYNC Setup Software Utility

(Windows Only)

The optional SYNC Setup software utility requires the following:

- ◆ A Digidesign-qualified Windows computer.
- ◆ An available COM port or serial port on the computer to connect to the SYNC HD. (You cannot run the SYNC Setup software utility from the DigiSerial port on Pro Tools cards.)

 *The computer requirements for the SYNC Setup software utility are different from the computer requirements for Pro Tools. You can run the SYNC Setup software utility from slower computers.*

- ◆ A non-standard 8-pin to 9-pin cable is required to connect the SYNC HD to a COM port or serial port on a Windows computer. Wiring instructions for making the required cable are in Appendix C, "Wiring Diagrams and Pin Assignments."

Digidesign Registration

Review the enclosed Digidesign Registration Information Card and follow the instructions on it to quickly register your purchase online. Registering your purchase is the only way you can be eligible to receive complimentary technical support and future upgrade offers. This is one of the most important steps you can take as a new user. Registering your purchase is the only way you can be eligible to receive:

- Complimentary technical support
- Any available software updates
- Future upgrade offers

About the Pro Tools Guides

In addition to the printed guides that came with your system, PDF versions of the Pro Tools guides are installed automatically with Pro Tools in the Documentation folder in the Pro Tools folder. To view or print the PDF guides, use Adobe Reader.


About This Guide

This guide assumes:

- You understand the basics of synchronization and time code
- You know how to operate devices that send or receive time code, such as a video deck
- You have an understanding of the time code requirements for your projects

This Guide covers use of the SYNC HD with Pro Tools HD version 7.3 and higher.

Use of tri-level synchronization rates requires Pro Tools HD version 7.4 or higher.


 *For versions of Pro Tools lower than 7.3, the SYNC HD can be set to emulate a SYNC I/O. See the Digidesign website (www.digidesign.com) for a version of the SYNC I/O Guide that applies to your system.*


Conventions Used in This Guide


Digidesign guides use the following conventions to indicate menu choices and key commands:


| Convention | Action |
|---------------|--|
| File > Save | Choose Save from the File menu |
| Control+N | Hold down the Control key and press the N key |
| Control-click | Hold down the Control key and click the mouse button |
| Right-click | Click with the right mouse button |

The following symbols are used to highlight important information:

 *User Tips are helpful hints for getting the most from your system.*

 *Important Notices include information that could affect your data or the performance of your system.*

 *Shortcuts show you useful keyboard or mouse shortcuts.*

 *Cross References point to related sections in other Digidesign guides.*

About www.digidesign.com

The Digidesign website (www.digidesign.com) is your best source for information to help you get the most out of your Pro Tools system. The following are just a few of the services and features available.

Product Registration Register your purchase online. See the enclosed Digidesign Registration Information Card for instructions.

Support and Downloads Contact Digidesign Technical Support or Customer Service; download software updates and the latest online manuals; find the latest system requirements; search the online Answerbase or join the worldwide Pro Tools community on the Digidesign User Conference.

Training and Education Become a certified Pro Tools Operator or Expert; study on your own using courses available online, or find out how you can learn in a classroom setting at a certified Pro Tools Training Center.

Products and Developers Learn about Digidesign products; download demo software; learn about our Development Partners and their plug-ins, applications, and hardware.

News and Events Get the latest news from Digidesign or sign up for a Pro Tools demo.

To learn more about these and other resources available from Digidesign, visit the Digidesign website (www.digidesign.com).

chapter 2

Installation and Configuration

Hardware Connections

The following are the primary hardware connections on a SYNC HD:

- AC Power
- Serial to a DigiSerial port on a Pro Tools PCI or PCIe card, or a serial port on the computer
- Clock to Pro Tools audio interfaces (Loop Sync or Super Clock)
- 9-pin to external machines (requires the Digidesign MachineControl option)
- Synchronization, including positional and clock references to and from remote machines

AC Power

The SYNC HD AC connector accepts a standard AC Power Cable. The SYNC HD is auto power-selecting (100V to 240V) and will automatically work with a standard modular cable to connect to AC power receptacles in any country.


Serial Connections

Serial to Pro Tools Core Card

Pro Tools systems require a serial connection between the SYNC HD and an HD Core or Accel Core card.

To connect the SYNC HD to an HD Core or Accel Core card:

- 1** Make sure power is off on all equipment.
- 2** Connect one end of the included serial cable to the SYNC HD Host Serial port.
- 3** Connect the other end to the DigiSerial port on your HD Core card.

 *Do not use the DigiSerial port on any other Pro Tools HD card in your system.*

Serial Connections for the SYNC Setup Software Utility

(Windows Only)

Any system using the optional SYNC Setup software utility requires a serial connection from the SYNC HD to a supported Windows computer. (For compatibility information, see “System Requirements” on page 3.)

⚠ *The SYNC Setup software utility will not control the SYNC HD through the DigiSerial port.*

To connect the SYNC HD to a Windows computer for the SYNC Setup software utility:

- 1 Purchase or make the required 9-pin to 8-pin cable. For wiring details, see “” on page 90.
- 2 Make sure power is off on all equipment.
- 3 Connect the SYNC HD Host Serial port to an available serial or COM port on your computer.
- 4 Restore power to the SYNC HD, and restart your computer.

Clock for Pro Tools Audio Interfaces


The SYNC HD must be connected to all Pro Tools|HD interfaces in the Loop Sync chain.

Connecting Loop Sync for Pro Tools|HD Systems

The SYNC HD supports Loop Sync, and can serve as Loop Sync Master. Loop Sync is a dedicated clock loop for synchronizing multiple Pro Tools|HD interfaces. Loop Sync should only be used to connect multiple Pro Tools|HD interfaces.

To connect the SYNC HD to Pro Tools|HD interfaces:


- 1 Using a BNC cable, connect the Loop Sync Out of the SYNC HD to the Loop Sync In of your primary Pro Tools|HD audio interface.
- 2 Using a second BNC cable, connect the SYNC HD Loop Sync In to the Loop Sync Out of your Pro Tools|HD interface.



96 I/O Interface

Loop Sync connections between a SYNC HD and 96 I/O

When using more than one Pro Tools|HD audio interface, make the SYNC HD the first and last unit in the Loop Sync chain.



HD Interfaces


Loop Sync in an expanded Pro Tools|HD system

Using Legacy Audio Interfaces with Pro Tools|HD

If you are using a Pro Tools|HD system that includes a legacy audio interface (an 888|24, 882|20, 1622, or ADAT Bridge audio interface), you will need to connect the Clock output of the HD system to the Slave Clock Input of the legacy interface.


To connect a legacy audio interface to an HD-series system with the SYNC HD:

- 1 Connect the SYNC HD to the HD-series system with Loop Sync as described in the previous steps.
- 2 Using a BNC cable, connect the Ext Clock Out of your primary HD-series interface to the Slave Clock In of your first legacy interface.




Clock for SYNC I/O, a 96 I/O, and an 888|24 I/O

- 3 If you are connecting multiple legacy interfaces, daisy-chain their Slave Clock connections by connecting the Slave Clock Out of the first interface to the Slave Clock In of the next interface.

 See the *Getting Started with HD Guide* for external clock configuration instructions.

MachineControl

On MachineControl-enabled Pro Tools systems, the SYNC HD supports limited Serial Deck Control only.

 For more information on MachineControl connections and operation, refer to the *MachineControl Guide*.

Serial Deck Control Mode


(Non-Linear Decks Only)

Limited Serial Deck Control mode is available through a connection to the 9-pin ports on the SYNC HD. For full Serial Deck Control, a direct serial connection to the host computer is required. See the MachineControl Guide for more information.

To connect an external deck to SYNC HD:

- ◆ Connect a standard 9-pin cable from one of the 9-pin Out ports on the SYNC HD to the 9-pin connector of the external deck.

As many as two decks can be connected to the two 9-pin Out ports on the SYNC HD. You can control one deck at a time, and switch between them from within Pro Tools. These ports on the SYNC HD support all MachineControl modes except 9-Pin Remote (Deck Emulation) mode.

 Due to performance limitations, this configuration should be used primarily with non-linear decks.

Remote 9-Pin Deck Emulation Mode

Remote 9-Pin Deck Emulation mode requires a direct serial connection to the host computer. See the MachineControl Guide for more information.

Synchronization and Time Code Connections to Machines, Decks, and Other Devices


The following sections describe connections required for different applications. For more information on time code applications, see Appendix A, “Additional Synchronization Information.”

Connecting a Video Source

This section describes connections required when using house video reference (SD or HD).

To have the SYNC HD resolve to house sync:

- Connect the house video reference/black burst/tri-level sync source to the Video Ref In port on the SYNC HD.


 *The Video Ref ports are a non-terminated loop-through connection. If the Video Ref Out port is not used, then you must terminate it using the included 75-ohm BNC terminator.*

To have the SYNC HD resolve directly to an incoming SD video signal:

- Connect an SD video signal to the SYNC HD Video In port.

Character Generator for Window Burn

The SYNC HD can generate a window burn on SD signals coming in to the Video In port.

 *Even when you have an HD video reference signal connected to the Video Ref In connector, you can still connect an SD video signal to the Video In connector to provide a window burn.*

To use the SYNC HD Time Code Character Generator to make a window burn (SD signal):

- 1 Connect an SD video signal to the SYNC HD Video Ref In port.
- 2 Connect the SYNC HD Video Ref Out port to the Video In port.
- 3 Connect the SYNC HD Video Out port to other video devices, ensuring that the signal is terminated by the last device in the chain.

Connecting LTC

The SYNC HD provides LTC input and output connectors.

To input LTC to the SYNC HD:

- Connect the LTC signal from your machine, synchronizer or other source to the SYNC HD LTC In port.

To output LTC from the SYNC HD:

- Connect the SYNC HD LTC Out port to your external devices.

Connecting Word Clock Devices

The SYNC HD has Word Clock input and output, both of which can be used simultaneously. Use Word Clock when you want the SYNC HD to lock to 1x clock from DAT machines, DA-88s, and similar digital devices.

Pro Tools|HD audio interfaces each have their own Word Clock inputs, which provide additional clock options and flexibility. Refer to Pro Tools|HD documentation for details.

To input Word Clock to the SYNC HD:


- Connect Word Clock from the master Word clock signal or device to the SYNC HD Word Clock In.

To supply Word Clock from the SYNC HD:

- Connect the SYNC HD Word Clock Out to the Word Clock input of a digital device.

Make sure the SYNC HD Word Clock Out port is configured to 1x for Word Clock.


Word Clock contains no positional information. If you want devices to play or record in sync, you'll still need to provide them with a positional reference.

 *The SYNC HD can generate time code to provide positional reference to other devices. See “Generating & Regenerating Time Code” on page 49.*

Connecting AES/EBU Devices

To input AES/EBU clock reference to the SYNC HD:

- Connect the device's AES/EBU output to the SYNC HD AES/EBU input.



Connecting the SYNC HD to an AES/EBU device

To supply AES/EBU clock reference from the SYNC HD:

- Connect the SYNC HD AES/EBU output to the AES/EBU reference input on a DAT machine or other digital device. (AES/EBU clock does not support 176.4 kHz or 192 kHz sample rates.)

Connecting MIDI

The SYNC HD MTC Out port supplies MIDI time code, derived from conversion (from LTC, VITC or Bi-Phase) or from MTC generation, to synchronize MTC-compatible consoles, sequencers, lighting systems, and other devices.

MIDI time code from the MTC Out always matches the time code address displayed on the SYNC HD front panel. To supply MTC from the SYNC HD to another MTC-compatible device, connect the device as described below.

To connect an MTC-compatible device to receive MTC from the SYNC HD:

- Connect the SYNC HD MTC Out port to the appropriate MIDI input on the device using a standard MIDI cable.

Pro Tools and MTC

Pro Tools receives MTC from the SYNC HD through its connection to the SYNC HD Host Serial port. This signal does not include standard MIDI time code, but is instead a high-quality, proprietary time code signal designed for Pro Tools. A MIDI Interface is not required for Pro Tools to receive MTC.

MTC is output constantly whenever the SYNC HD is generating time code. This output can be muted when time code (LTC) is idle. See “MTC Output and Idle Muting” on page 56 for details.

Software Installation

The following sections provide instructions to install software required to use the SYNC HD with Pro Tools HD or with the stand alone SYNC Setup software (Windows only).

Pro Tools HD

All software required to use SYNC HD options is installed with Pro Tools HD software.



The availability of SYNC HD features depends on the version of Pro Tools software you are running. For details on features available with your version of Pro Tools, visit the DigiDesign website.


Updating SYNC HD Firmware

You can update SYNC HD firmware from the DigiTest application.

To update SYNC HD firmware:

- 1 Confirm that the SYNC HD is properly connected to your computer in one of the following ways:
 - If it is connected to a Pro Tools system, it should be connected to a DigiSerial Port on an HD Core card.
 - (Windows Only) If it is connected to a computer without Pro Tools, it should be connected to the COM 1 port on the computer with a standard serial cable.
- 2 Ensure that Pro Tools is not running.
- 3 Launch the DigiTest application.

4 Click SYNC Firmware.



DigiTest SYNC Firmware window

- 5 If you are using a DigiSerial Port connection, make sure you have selected the HD Core card from the pop-up menu.
- 6 Select the type of port connection for the SYNC peripheral (DigiSerial Port or COM Port).
- 7 Select SYNC HD for the Synchronizer Type.
- 8 Click Begin Update.
- 9 Follow the on-screen instructions to power cycle the SYNC HD while holding the Set button.
- 10 Wait for the firmware update to complete. Do not power off the SYNC HD while the update is in progress.
- 11 When the update is complete, click Quit.

SYNC Setup Software Utility (Windows Only)

When using the SYNC HD in Standalone mode, the SYNC HD can be controlled remotely using the SYNC Setup software utility. Updates to this utility can be downloaded from the Digidesign website (www.digidesign.com).

To install the SYNC Setup software utility on Windows:

- 1 Make sure the SYNC HD is connected to a serial or COM port on your computer. See “Serial Connections for the SYNC Setup Software Utility” on page 8.
- 2 Insert the installer disc containing the latest SYNC Setup software, or navigate to its location if you downloaded an update.
- 3 Launch the installer and follow the on-screen instructions.

Configuring the Device ID

- ◆ If you are using SYNC HD with Pro Tools HD 7.4 or higher, Pro Tools will automatically recognize the SYNC HD.
- ◆ If you are using SYNC HD with Pro Tools HD version 7.3 or lower, set SYNC HD to emulate a SYNC I/O.

To set SYNC HD to emulate a SYNC I/O:


- 1 Press Set, and use the Up or Down switches to display Device ID (dEuicE id).
- 2 Press Set. The LED Time Code Display shows the current Device ID for the unit: SYNC HD (SYnc HD) or SYNC I/O (SYnc IO).
- 3 Press Up and Down to toggle the Device ID to read SYNC I/O (SYnc IO).
- 4 Press Set.

Configuring the SYNC HD from Pro Tools HD

Pro Tools HD software provides SYNC HD configuration controls that establish communication between Pro Tools and the SYNC HD.

Loop Sync

The SYNC HD supports Digidesign's Loop Sync feature for connecting Pro Tools|HD interfaces. The SYNC HD can be configured as the Clock Source (Loop Master) in order to provide Loop Sync master clock to the rest of your Pro Tools|HD interfaces.


 For system requirements and Loop Sync connection instructions, see Chapter 1, "Introduction."

Auto ID of SYNC HD through Loop Sync

Pro Tools HD automatically recognizes if a SYNC HD is connected to the DigiSerial port when Pro Tools is launched. When Pro Tools recognizes the SYNC HD, it automatically configures the Device and Port settings for the SYNC HD in the Peripherals dialog

To check SYNC HD and Pro Tools communication:

- 1 After installing Pro Tools and connecting the SYNC HD as described, launch Pro Tools.
- 2 Choose Setup > Peripherals, and click the Synchronization tab.
- 3 Under Digidesign Synchronization Device, select Enable SYNC Peripheral.




SYNC HD settings in the Peripherals dialog

Pro Tools scans the DigiSerial port and checks the SYNC HD firmware.


If you need to update your firmware, use the DigiTest application included on the SYNC HD Installer disc. See "Updating SYNC HD Firmware" on page 12.

Configuring the SYNC HD in the Session Setup Window

When the SYNC HD is connected through Loop Sync and enabled in the Peripherals dialog, its settings become available in the SYNC Setup and Time Code Settings sections of the Session Setup window.




Session Setup window

 See the Pro Tools Reference Guide for more information on the Session Setup Window.

Clock Source

When connected and configured in the Loop Sync chain, the SYNC HD appears (as SYNC) along with any Pro Tools|HD interfaces in the Clock Source pop-up menu, located in the Session Setup window.



SYNC HD selected as Clock Source in the Session Setup window


Clock Source can be any device in the Loop Sync chain. This lets you use any digital input source available on any Pro Tools|HD interface (including the SYNC HD) simply by selecting that device and source from the Clock Source menu.

Clock Reference

The selected Clock Source device determines your choices for clock reference.

When Clock Source is the SYNC HD

When the SYNC HD is set to be the Clock Source, it is the Loop Master. Clock, Positional Reference, and Video Format selectors become active in the SYNC Setup section of the Session Setup window.




SYNC Setup controls in the Session Setup window

SYNC HD Clock Reference choices include:


- Internal/VSO
- Video In
- Video Reference (SD)
- Video Reference (HD)
- LTC
- Bi-Phase
- Pilot Tone
- AES/EBU
- Word Clock
- Loop Sync

When the SYNC HD is not the selected Clock Source device, the Clock Reference menu in the SYNC Setup section switches to Loop Sync.

 For LTC clock reference, multiple choices are available from the LTC sub-menu. See “LTC and Clock Reference” on page 38.

To choose a SYNC HD Clock Reference:

- Select a SYNC HD clock choice from the Clock Reference pop-up menu in the Session Setup window.



Choosing a SYNC HD Clock Reference

The Clock Source pop-up menu follows your selection of SYNC HD for Clock Reference by automatically switching to the SYNC setting. (You can also choose SYNC HD as Clock Source first, then select a Clock Reference.)

To choose a different Loop Sync device as the Clock Source:


- Select a different Loop Sync device and Clock Source from the Clock Source pop-up menu in the Session Setup window.



Choosing a Clock Source (96 I/O shown)


When Clock Source is an HD I/O

When a 192 I/O, 192 Digital I/O or 96 I/O is providing the Clock Source, it will be the Loop Master. Clock Source options are available directly from the Clock Source menu, based on the configuration of that interface in the Hardware Setup dialog. Choices can include AES, S/PDIF, Optical, or Word Clock.

 See the *Getting Started with HD Guide* for more information on audio interface configuration.

Locked and Speed Cal Indicators

The Locked and Speed Cal indicators in the SYNC Setup and Timecode Offsets section of the Session Setup window display synchronization status of the SYNC HD. These indicators reflect the state of the same LEDs on the front panel.



Locked and Speed Cal Indicators

Locked The Locked indicator stays lit when the SYNC HD is locked to the selected clock reference. The Locked indicator flashes if the selected clock reference source is missing or out of lockable frequency range.

Speed Cal The Speed Cal indicator lights to indicate the status of the clock reference:

- Yellow Solid: SYNC HD is locked and that the clock reference is within 0.025% of the expected rate
- Yellow Flashing Fast: SYNC HD is locked, but the clock reference is between 0.025% and 4% faster than the expected rate
- Yellow Flashing Slow: SYNC HD is locked, but the clock reference is between 0.025% and 4% slower than the expected rate
- Red Flashing Fast: SYNC HD is locked, but the clock reference is more than 4% faster than the expected rate
- Red Flashing Slow: SYNC HD is locked, but the clock reference is more than 4% slower than the expected rate
- Unlit: SYNC HD is not locked to the chosen clock reference

Positional Reference

To select a positional reference:

1 Select a positional reference from the Positional Reference pop-up menu, located in the SYNC Setup controls.

When the Positional Reference choices include:

- Auto LTC/VITC
- LTC
- VITC
- Bi-Phase

Sample Rate

The SYNC HD sample rate is determined by the current Pro Tools session sample rate. In Standalone mode, SYNC HD sample rate can be selected with the SYNC Setup software utility (Windows only), or using the front panel switches. Current sample rate is indicated by the Sample Rate LEDs.

When used with Pro Tools HD, the SYNC HD supports all available sample rates. Setting the session rate in Playback Engine or Hardware Setup dialogs also sets the SYNC HD to that sample rate.

Audio and Video Pull Up and Pull Down

Pro Tools provides up to 4.167% pull up, and 4.0% pull down choices. When working with a Movie track containing video, a separate Video Pull-Down menu becomes available in the Session Setup window, allowing you to apply standard or non-standard pull factors to audio and video separately. This lets Pro Tools synchronize to most supported SMPTE frame rates and formats.


⚠ *With Pro Tools HD, 4.167% pull up and 4.0% pull down are not available in 176.4 kHz and 192 kHz sessions.*

Time Code Rate

While using Pro Tools, the SYNC HD Time Code Rate automatically follows the session Time Code Rate setting. Session Time Code Rate is set in the Session Setup window.

To set the session Time Code Rate:

- Choose a rate from the Time Code Rate selector in the Session Setup window.




Choosing a session Time Code Rate

In Standalone mode, the SYNC HD Time Code Rate can be set using the SYNC Setup software utility (Windows only), or from the front panel.

Video Ref Format

SD Video Reference


Choose PAL or NTSC format for the session from the Video Ref Format pop-up menu in the Session Setup window. If the session already has video, the format will be set automatically.



Choosing an SD Video Format

HD Video Reference

Choose the video reference rate for the session from the Video Ref Format pop-up menu in the Session Setup window. If the session already has video, the format will be set automatically.



Choosing an HD Video Format

The following video reference rates are available in the Video Ref Format pop-up menu:

- Slow PAL 23.976
- Slow PAL 24
- 720p - 23.976
- 720p - 24
- 720p - 25
- 720p - 29.97
- 720p - 30
- 720p - 50
- 720p - 59.94
- 720p - 60
- 1080i - 47.95
- 1080i - 48
- 1080i - 50
- 1080i - 59.94
- 1080i - 60
- 1080i - 59.94
- 1080i - 60
- 1080p - 23.976
- 1080p - 24
- 1080p - 25
- 1080p - 29.97
- 1080p - 30
- 1080p - 50
- 1080p - 59.94
- 1080p - 60

Video In Format Settings at HD Video Reference Rates

When the Clock Reference is set to Video Reference (HD), SYNC HD automatically sets the Video In format (NTSC or PAL) appropriate for the selected Video Reference rate, as shown in the following table.

| Video Reference (HD) Rate | Video In Format |
|---------------------------|----------------------|
| Slow PAL 23.976 | NTSC |
| Slow PAL 24 | PAL |
| 720p - 23.976 | NTSC |
| 720p - 24 | PAL (NTSC available) |
| 720p - 25 | PAL |
| 720p - 29.97 | NTSC |
| 720p - 30 | NTSC |
| 720p - 50 | PAL |
| 720p - 59.94 | NTSC |
| 720p - 60 | NTSC |
| 1080i - 47.95 | NTSC |
| 1080i - 48 | PAL (NTSC available) |
| 1080i - 50 | PAL |
| 1080i - 59.94 | NTSC |
| 1080i - 60 | NTSC |
| 1080p - 24 | PAL (NTSC available) |
| 1080p - 25 | PAL |
| 1080p - 29.97 | NTSC |
| 1080p - 30 | NTSC |
| 1080p - 50 | PAL |
| 1080p - 59.94 | NTSC |
| 1080p - 60 | NTSC |

With 24-frame and 48-frame rates only, a pop-up menu lets you set the Video In Format.

Clock Reference, Video Ref In, and Video In Settings when Importing Avid Video

When you import Avid video media into a session, Pro Tools automatically sets the Clock Reference (HD or SD), Video Reference rate, and Video In format appropriate for the imported media.

MachineControl Configuration

If you are using Digidesign MachineControl, do the following to establish basic communication.

To configure MachineControl:

- 1 Choose Setup > Peripherals, and click the Synchronization tab.
- 2 In the Synchronization page, ensure the SYNC HD is the current Synchronization device, and DigiSerial is the selected port.
- 3 Click the MachineControl tab to open the MachineControl page.
- 4 Enable and configure options for 9-pin Serial or 9-pin Remote.

Selecting Transport Master

The Pro Tools Transport window provides the Transport Master selector. This pop-up lets you select the device that will be controlled by the Pro Tools transport. Choices include Pro Tools and any other devices or modes you have enabled in the Synchronization or Machine Control tabs of the Peripherals dialog.



Transport master

Software Configuration for the SYNC Setup Software Utility

(Windows Only)

To configure the SYNC Setup software on Windows:

- 1 Make sure the SYNC HD is connected to your computer according to the instructions in “Serial Connections” on page 7.
- 2 Launch the SYNC Setup software utility.
- 3 Choose Preferences > SYNC Set menu in the upper left corner of the SYNC Setup application.
- 4 If not already selected, choose the appropriate serial port for the SYNC HD-to-computer connection.
- 5 Close the Preferences window. The SYNC Setup software utility should now show that it recognizes the SYNC HD in the information display section. If it does not, check your connections and port selection, and try again.


Troubleshooting

Status LEDs

The status LEDs (LOCKED and SPEED CAL) on the SYNC HD front panel and in the Session Setup window may help you isolate potential problems.

Use the Incoming Time field in Pro Tools Session Setup Window as a Reference

The Incoming Time field in the Session Setup Window indicates whether or not the SYNC HD is receiving positional reference. If this field appears to be inactive when inputting time code to the SYNC HD, check your hardware device settings, serial connection to your computer, and your software settings.



Incoming Time Code display (Session Setup window)

Lost Communication

If Pro Tools loses communication with the SYNC HD, a dialog will appear asking you whether you want to switch to MTC (if available) or continue trying to locate the SYNC HD. If you see a “lost communication” dialog, first check power, DigiSerial, and other connections.

Lost Communication Dialog

The Lost Communication dialog provides the following options for re-establishing synchronization when communication with the SYNC HD stops:

Use MTC Click this button if the SYNC HD is unavailable, to switch to any currently connected MIDI interface for MTC synchronization. This option requires a compatible device that supports MTC conversion, and that is already connected to your CPU and enabled.

Keep SYNC Click this to leave the session configured for the SYNC HD, or to continue searching for the SYNC HD to re-establish lost communication.

Synchronization Accuracy

If you are noticing drift or lack of accurate synchronization between your devices, check the following:

- ◆ If your system locks up in the wrong place, make sure you have set the correct frame rate and format (NTSC or PAL) on all your devices.
- ◆ If your system locks up in the correct location, but drifts, check your clock signals and settings.

chapter 3

SYNC HD Hardware and Software

SYNC HD Front Panel




Figure 1. SYNC HD front panel

Controls and Displays

All SYNC HD local controls are on its front panel. For information on back panel connectors and setup, see Chapter 2, “Installation and Configuration.”

AC Mains Power Switch

When the SYNC HD power switch is pressed in, power is *on*; when the switch is out, power is *off*.

The LED ring around the power switch is orange while the SYNC HD is powering up, or while firmware is being updated. The LED ring is green when the SYNC HD is ready for use.

Clock Reference Switch and LEDs

This switch selects the SYNC HD clock reference, as indicated by the Clock Reference LEDs. Available clock reference inputs include:

- Video Ref SD/HD (Green = SD, Yellow = HD)
- Video In
- LTC
- Word/AES (Green = Word, Yellow = AES)
- Pilot
- Bi-phase/Tach
- Internal/VSO
- Loop Sync

Loop Master Indicator

When lit, this LED indicates that the SYNC HD is the current Pro Tools Loop Master device.

Table 4. Sample Rates at Pull Up and Pull Down Settings

| Pull Up/Down | Sample Rate | | | | | |
|--------------------|-------------|-------|-------|--------|--------|--------|
| | 44100 | 48000 | 88200 | 96000 | 176400 | 192000 |
| +4.1667% and +0.1% | 45983 | 50050 | 91967 | 100100 | n/a | n/a |
| +4.1667% | 45938 | 50000 | 91875 | 100000 | n/a | n/a |
| +4.1667% and -0.1% | 45892 | 49950 | 91783 | 99900 | n/a | n/a |
| +0.1% | 44144 | 48048 | 88288 | 96096 | 176576 | 192192 |
| -0.1% | 44056 | 47952 | 88112 | 95904 | 176224 | 191808 |
| -4.0% and +0.1% | 42378 | 46126 | 84757 | 92252 | n/a | n/a |
| -4.0% | 42336 | 46080 | 84672 | 92160 | n/a | n/a |
| -4.0% and -0.1% | 42294 | 46034 | 84587 | 92068 | n/a | n/a |

Sample Rate LEDs

These green or yellow LEDs show the current SYNC HD sample rate. Pull Up and Pull Down are available for all sample rate settings, indicated by the corresponding LED. Table 4 (above) shows the actual sample rates when pulled up or down.

Generator/Parameter Controls

These four switches provide direct access to many SYNC HD functions, including time code generator settings, PAL/NTSC selection, sample rate and more. The Time Code LED display shows the current mode, selected parameter, or setting.


Time Code Display

This 7-segment, multifunction LED is the SYNC HD time code and parameter display.

Time Code The current positional reference (internal or external), is displayed in hours:minutes:seconds:frames. Odd/even field distinction is indicated using a decimal point to the right of the frames display. A lit decimal point to the right of frames indicates an even-numbered field; no decimal point indicates an odd-numbered field. When the SYNC HD is in Auto Switch LTC/VITC mode, the decimal point to the right of “minutes” illuminates.

The SYNC HD Time Code Display always displays actual incoming time code, regardless of any External Time Code Offsets settings that are applied in Pro Tools.

Parameters and Values When configuring the SYNC HD with the Set, Run/Stop and other parameter controls, the LED display shows parameter names, values, and other data.

 For a table identifying each LED abbreviation and function, see “Parameters” on page 59.

Positional Reference Switch

This switch selects the positional reference source, as indicated by the Positional Reference LEDs. Choices include LTC, VITC, Auto Switch Bi-phase, and Generate.

In Auto Switch LTC/VITC mode, both the LTC and VITC LEDs light while the SYNC HD determines which source it will use. Either the LTC or the VITC LED will remain lit to indicate the chosen positional reference.

Frame Rate Switch

This switch selects the time code frame rate and format (drop-frame or non drop-frame). The active choice is displayed by the Frame Rate and DF (drop frame) LEDs.

Frame Rate LEDs and DF Indicator

These display the current SYNC HD frame rate: 30, 29.97, 25, or 24 fps are indicated by four green LEDs. The DF LED indicates drop-frame (lit) or non drop-frame (unlit). The 24 fps LED will blink to indicate 23.976 fps.

Status LEDs


These LEDs show the current state of the SYNC HD in relation to clock references. Indicators include:

Locked This LED lights solid green when the SYNC HD is locked to the selected clock reference. The Locked LED flashes yellow if the selected clock reference source is missing or out of lockable frequency range.

Speed Cal (Speed Calibration) This LED lights to indicate the status of the clock reference:

- Yellow Solid: SYNC HD is locked and that the clock reference is within 0.025% of the expected rate
- Yellow Flashing Fast: SYNC HD is locked, but the clock reference is between 0.025% and 4% faster than the expected rate
- Yellow Flashing Slow: SYNC HD is locked, but the clock reference is between 0.025% and 4% slower than the expected rate
- Red Flashing Fast: SYNC HD is locked, but the clock reference is more than 4% faster than the expected rate
- Red Flashing Slow: SYNC HD is locked, but the clock reference is more than 4% slower than the expected rate
- Unlit: SYNC HD is not locked to the chosen clock reference

Remote Mode This green LED lights when the SYNC HD is set to Remote-Only/Front Panel Lockout mode. While this LED is lit, the front panel switches will have no effect on the SYNC HD.

 For more information, see “SYNC Setup Dialog Controls and Displays” on page 28.

SYNC HD Back Panel





Figure 2. SYNC HD Back Panel

Bi-Phase/Tach/GPI/Pilot

This is an accessory port for Bi-Phase, Tach, and Pilot signals (specific cables are required for different applications). This connector is also used for GPI input, output (including Fader Start), and thru signals. This port handles up to 12 V Bi-phase.

 Refer to Appendix C, “Wiring Diagrams and Pin Assignments” for wiring information and other specifications for this port.


Video Reference In/Out

Video Ref In Receives a signal from an SD (NTSC/PAL) or HD (tri-level or bi-level) video source (such as a black burst (house sync) generator or a standard video signal) for purposes of clock reference.

This port is configured as an un-terminated loop-through. When you connect a signal to this port, you must do one of the following:

- Connect a 75-ohm BNC terminator (included with the SYNC HD) to the Video Reference Out on the back panel
- or –
- Make sure another terminated video device is fed from the Video Reference Out connector.

Video Ref Out A parallel, unbuffered connection output for any video source connected to the Video Reference In port. This port allows black burst or other video reference to be passed to another device, and continues to output whatever signal is present at the Video Reference In port, whether the SYNC HD is on or off.

 If the SYNC HD is the last device in the video sync chain, a 75-ohm BNC terminator must be attached to this connector.

Host Serial Port

The Host Serial port is a bidirectional (in/out) port to connect the SYNC HD to the DigiSerial Port on a HD Core card. When not being used with Pro Tools, the SYNC HD Host Serial port can be connected to a standard serial port on a supported computer to run the SYNC Setup software utility (Windows only).

Video In/Out

Video In Receives a signal from an SD (NTSC/PAL) video source for clock or VITC positional reference input, or for generating a window burn. This connector is internally terminated at 75 ohms.

The Video In connector does not accept HD reference signals.

Video Out Output of the current Video In signal. If the Positional Reference is set to Generate and the Clock Reference is set to one of the two video inputs, this will output a copy of the video signal appearing at the Video Reference In. In either case, this output can also carry VITC and/or Window Burn information if those features are enabled.

MTC Out

The MTC Out will output MIDI Time Code (MTC), only. No other MIDI data appears at this output. MTC output can be regenerated while the SYNC HD is locked to any supported positional reference and clock reference, or internally generated in Generate mode, in which case MTC output follows generator run/stop. This port is intended to supply MTC from the SYNC HD to external sequencers or other MIDI devices.

MTC is output constantly whenever the SYNC HD is generating time code. This output can be muted when time code (LTC) is idle. See “MTC Output and Idle Muting” on page 56 for details.

LTC In/Out

LTC In Receives a Linear Time Code (LTC) source, balanced or unbalanced analog, for positional and/or clock reference. This port is often used to receive LTC from an audio track on an external deck or the address track of a VTR. Adjustable LTC servo gain is available in Pro Tools and from the front panel.

LTC Out Outputs linear time code, in balanced or unbalanced analog audio format. See Appendix C, “Wiring Diagrams and Pin Assignments” for wiring details. LTC output level is also adjustable using the SYNC Setup software utility (Windows only), the controls on the front panel of the SYNC HD, or the Synchronization page of the Peripherals dialog in Pro Tools.

AES/EBU In/Out

AES/EBU In Receives an AES/EBU digital audio signal, for clock reference purposes only. The SYNC HD utilizes only the signal's clock information, not the audio information. If digital audio information is present at this input, it will be ignored and not passed through to the AES/EBU digital output connector.

AES/EBU Out Outputs a silent (all bits OFF) AES/EBU audio signal whose sample rate exactly matches the SYNC HD sample clock

Word Clock In/Out

Word Clock In Receives (1x sample rate) Word Clock, for clock reference purposes only. Word Clock is often used with external digital consoles and digital tape machines.


Word Clock Out Outputs 1x sample rate Word Clock information (for Word-clock capable peripherals) or 256x Slave Clock information (for Legacy peripherals). This port is configured using the SYNC Setup software utility on Windows (Word Clock Out), or the controls on the front panel of the SYNC HD.

9-Pin Out 1 and 2

For Digidesign MachineControl-enabled systems, these two ports connect directly to external 9-pin transports, and provide limited Serial Deck control capability.

For best performance on Windows systems, use the COM ports on the Windows computer.

For best performance on Mac systems, use a Key-span USA28XG USB serial adapter.

 See the MachineControl Guide for more information.

Loop Sync In/Out

Loop Sync is the clock signal used to synchronize Pro Tools|HD interfaces.

Loop Sync In Receives Loop Sync from any Pro Tools|HD interface.

Loop Sync Out Provides Loop Sync. This port connects to the primary Pro Tools|HD interface.


AC Power

The SYNC HD accepts a standard power cable and is auto voltage-selecting (100V to 240V).


SYNC Setup Software Utility

(Windows Only)

This section reviews the SYNC Setup controls and displays included with the SYNC Setup software utility.

 For SYNC Setup software utility requirements, see “Software Installation” on page 12.

SYNC Setup Dialog Controls and Displays



SYNC Setup dialog (SYNC Setup software utility)

SYNC Setup Software Utility Help

- Right-click anywhere in the SYNC Setup dialog and select Help, or press the F1 key.

Time Code Window

The time code display mirrors the LED Time Code Display on the SYNC HD front panel, displaying (in hours:minutes:seconds:frames) the time code address of the current positional reference.

When the SYNC HD is reading odd-numbered fields, the separator changes from a normal colon (:) to a period (.); when it's reading even-numbered fields, the punctuation returns to a colon (:). Odd/even status is only available while reading VITC, and only when VITC is within a speed range from zero to about 50% of playback speed.

Clock Reference

This control selects the SYNC HD clock reference.

Sample Rate

This control selects the SYNC HD sample rate (or the Pro Tools session sample rate, if applicable).

Pull Rate

This control Enables Pull Up or Pull Down for the current sample rate.

Word Clock Out

This control configures the SYNC HD Word Clock Output between 256x (Super Clock) and the current session rate (1x at 44.1 kHz, or 1x at 48 kHz). Only Legacy audio interfaces require 256x Super Clock.

Positional Reference

This control selects the SYNC HD positional reference.

Frame Rate


This control selects the frames-per-second (fps) rate of external (or internally generated) time code.

Status Display

This display shows the current state of the SYNC Setup software utility in relation to the SYNC HD and external devices, as follows:

Resolver Locked Lights when the SYNC HD is locked to the chosen external clock reference, or to its *Internal* clock reference.

Speed Calibration Lights when the SYNC HD system clock and all output clocks are at a frequency that corresponds with the chosen sample rate. Capable of indicating mismatch of pull-up, pull-down and frame rate.

 For details about Speed Calibration characteristics, see "Status LEDs" on page 25.

Regenerator Locked Lights when the SYNC HD is regenerating time code at its video, LTC, and MTC outputs locked with the incoming positional reference source. Also lit whenever the SYNC HD is generating time code internally.

Connected to SYNC I/O Lights when the SYNC Setup dialog is the front-most window and is communicating with the SYNC HD.

Waiting for SYNC I/O Lights when the SYNC Setup dialog is the front-most window and is unable to communicate with the SYNC HD.

Port Relinquished Lights when the SYNC Setup dialog is not the front-most window or is unable to allocate a serial port with which to communicate with the SYNC HD.

LTC Output Level

This control adjusts the analog audio level of the SYNC HD LTC output, from -24 dBu to +9 dBu.

Freewheel Duration

This control sets the period of time for which the SYNC HD will continue to supply positional reference data after an external source is interrupted or stopped (also referred to as Time Code Freewheel in Pro Tools).

Video Format

This control selects the format (NTSC or PAL) for both the incoming and outgoing video signals.

- ◆ NTSC is used in North and South America, Japan, and certain other parts of the world.
- ◆ PAL is used in most of Europe, Asia, and Africa. Users of SECAM video (for France, Russia, and certain other parts of the world) should select PAL.

VITC Read Lines

This control determines which line pair of incoming video signal is used for the VITC source. When set to Auto, the SYNC HD will search for the first valid line pair automatically. Alternatively, this value can be set to specific VITC line pairs.

VITC Generate Lines

This control determines the line pair of the outgoing video signal onto which the SYNC HD inserts VITC. Normally, this should be left at the default (and preferred) setting of 14/16.

VITC Insertion Enabled

When selected, VITC will be inserted into the outgoing video signal—assuming that a video signal is present at a SYNC HD video input, and that the SYNC HD is in a valid mode for inserting VITC. The only invalid positional reference modes are VITC or Auto Switch LTC/VITC. The SYNC HD can't read VITC and generate new VITC at the same time.

Pitch Memory Enabled

When selected, the SYNC HD will remain at a *pitch* (sample rate) that corresponds to the last known incoming time code speed. When deselected, the SYNC HD will revert to the selected sample rate. If Pitch Memory is disabled and the selected external clock reference is not available, then the SYNC HD will revert to the nominal, selected internal sample rate setting.

Idle MTC Enabled

Controls MTC Output during idle (play stopped). When enabled, MTC is continuously output. When not enabled, MTC output is muted when playback is idle. See “MTC Output and Idle Muting” on page 56 for details.

Dub Window

Settings for the SYNC HD character generator/window dubbing features. (These controls are also available from within the Pro Tools Peripherals dialog.) Complete Window Dub instructions are provided in the section “Generating a Window Dub” on page 57.

Bi-Phase/Tach Parameters

Used for specialized applications that involve film or other equipment that output Bi-Phase/Tach information. These parameters must be set to match the Bi-Phase or Tach source to achieve lock.

Generator/Bi-Phase Preset

Serves two functions, as determined by the current SYNC HD mode:

Generate Mode Sets the time code start time directly by clicking in the Hrs:Min:Sec:Frm fields and typing in a value. The Tab key will cycle through the fields.

Bi-Phase/Tach Mode Zeros the time code counter, to allow the SYNC HD to generate time code in relation to the pulses of the incoming Bi-Phase/Tach information. Establishes a time code start point (first frame of a reel, for example).

Variable Speed Override (VSO)

Used to varispeed the rate of the SYNC HD internal crystal-referenced clock (± 699 cents; a cent is one-hundredth of a semitone). VSO is available at any positional reference setting, but only when the clock reference is Internal/VSO.

chapter 4

Using SYNC HD

SYNC HD settings can be controlled in three ways:

From Pro Tools Provides access to most SYNC HD controls from within the Pro Tools Session Setup window or the Synchronization page of the Peripherals window.

From the SYNC HD Front Panel Provides access to most controls from the front panel when using the SYNC HD in Standalone mode.

From the SYNC Setup Software Utility (Windows Only) This optional utility provides remote access to all SYNC HD controls from a supported Windows computer.

For a listing of SYNC HD parameters supported in each method, see “SYNC HD Controls in Pro Tools, SYNC Setup Software Utility, and the SYNC HD Front Panel” on page 34.

About SYNC Setup Software Utility Remote-Only Mode

When the default Remote-Only Mode (Front Panel Lockout) is enabled in the SYNC Setup software utility Preferences window, none of the SYNC HD front panel switches are operational, and the Remote Only LED is lit.

To exit Remote-Only mode from the front panel:

- Simultaneously press and hold down the Clock Reference, Positional Reference, and Frame Rate front panel switches.

This will disengage the SYNC HD from Remote-Only mode. This is useful when the host computer is not easily accessible.

SYNC HD Controls in Pro Tools, SYNC Setup Software Utility, and the SYNC HD Front Panel

Table 5. SYNC HD controls in Pro Tools, SYNC Setup software utility, and the SYNC HD front panel

| Parameters | Available from/in: | | |
|--------------------------------|------------------------|-----------------------|-----------------------------|
| | Pro Tools | Front Panel | SYNC Setup Software Utility |
| Device ID | no | yes | no |
| Clock References | all (Session Setup) | all | all |
| Positional References | all (Session Setup) | all | all |
| Sample Rates | all | all | all |
| Pull Rates | yes (Session Setup) | yes | yes |
| Base Clock (Word Clock Out) | no | yes ("Base Clock") | yes ("Word Clock Out") |
| Frame Rates | all (Session Setup) | all | all |
| LTC Output level | yes (Peripherals/Sync) | yes | yes |
| LTC Servo gain | yes (Session Setup) | yes | no |
| Freewheel duration | yes (Session Setup) | yes | yes |
| Video Format (NTSC/PAL) | yes (Session Setup) | yes | yes |
| VITC Read Lines | yes (Peripherals/Sync) | yes | yes |
| VITC Generate Lines | yes (Peripherals/Sync) | yes | yes |
| VITC Insertion Enable | yes (Peripherals/Sync) | yes | yes |
| Pitch Memory Enable | yes (Peripherals/Sync) | yes | yes |
| Window Dub | all (Peripherals/Sync) | on/off only | yes, all |
| Bi-Phase/Tach Pulses/Frame | yes (Peripherals/Sync) | yes | yes |
| Bi-Phase/Tach Wiring | yes (Peripherals/Sync) | no | no |
| Gen/Bi-Phase Preset | yes (Session Setup) | yes | yes |
| GPI | yes | no | no |
| VSO | yes (Session Setup) | no | yes |
| Idle MTC Enable | yes (Peripherals/Sync) | yes | yes |

Front Panel Generator/Parameter Switches


The Generator/Parameter Controls are labelled SET, DOWN, UP, and RUN/STOP/CLEAR/ESC. In addition to their primary generator functions, these switches provide front panel access to most SYNC HD parameters.

Features Not Accessible from the SYNC HD Front Panel Controls

The front panel provides access to all SYNC HD features except the following, which can be controlled using Pro Tools or the SYNC Setup software utility (Windows only):

- Remote-Only Mode/Front Panel Lockout
- Changing Window Burn Size, Vertical Position, Horizontal Position, and Color
- GPI (General Purpose Interface) functions
- Variable Speed Offset (VSO)

For a listing of available parameters, see Table 5 on page 34.



Generator/Parameter Switches

Set

The SET switch has three primary functions:

When time code is displayed Press Set once to change the Display from time code to parameter names.

When a parameter name is visible Press Set once to change the Display to show parameter *values*.

When a parameter value is visible Press Set once to set the value for that parameter and return the Display to time code.

Down and Up

These switches scroll through parameter names or values:

When a parameter name is visible Press the Down and Up switches to scroll through the parameter names (for example, from “SET GEN” to “VidEo SY”).

When a parameter value is visible Press the Down and Up switches to scroll through the range of values for the current parameter.

When entering time code values Press the Down and Up switches simultaneously to cycle through the hours:minutes:seconds:frames fields in the time code display.

Run/Stop/Clear/Esc

This switch has two functions, depending on the current mode:

While generating time code Press RUN/STOP/CLEAR/ESC to start or stop the time code generator when the SYNC HD is in Generator Preset mode.

While time code is being displayed Press RUN/STOP/CLEAR/ESC to reset the counter whenever time code is visible in the LED Time Code display.

Otherwise, the RUN/STOP/CLEAR/ESC switch serves as a Cancel button.

Edit Mode

To enter Parameter/Value Edit mode:

- Press Set (when time code numbers are visible in the LED Time Code Display). The first press displays the first parameter name, “Set Gen,” (for the time code generator).

SE 7 6 En

The (default) first page of Generator Parameter controls

A different parameter may be displayed, depending on the previous SYNC HD settings.

To scroll through parameter choices:


- Press Up or Down to scroll through available parameters. Holding the switch scrolls through the parameters.

To select a parameter to edit:

- When the desired parameter is displayed, press Set. This will access that parameter’s current setting.

To edit parameter values:

- With parameter values displayed, press Up or Down to cycle through the available values.

 *For a complete listing of front panel Generator/Parameter controls, see Chapter 5, “Additional Operational Information.”*


Clock References and Options

The following sections explain each clock reference choice in detail. For basic instructions on selecting the clock or positional reference, setting frame rate, or setting the SYNC HD sample rate, see Chapter 2, “Installation and Configuration.”

Video Clock Options

The SYNC HD provides two video inputs, *Video Ref In* and *Video In*, which are each selectable for clock reference. (See “Video and Clock Reference” on page 37).

For House Video Reference (Black Burst) Use the Video Ref In connector.


 *The Video Ref ports are a non-terminated loop-through connection. If the Video Ref Out port is not used, then you must terminate it using the included 75-ohm BNC terminator.*

For Incoming Video Use the Video In connector.

Serial Time Code with MachineControl

MachineControl-equipped Pro Tools systems can utilize serial time code through either of the SYNC HD 9-pin ports. When using MachineControl with serial time code as the positional reference, the SYNC HD must be locked to a Video Reference. In this scenario, the SYNC HD is set to Generate mode to indicate that posi-

tional information is acquired by Pro Tools directly over the 9-pin cable, not through the SYNC HD. Refer to the *MachineControl Guide* for complete serial time code information.

 *MachineControl also provides 9-Pin Deck Emulation mode, but this mode is not supported through either of the SYNC HD 9-pin ports. See the Digidesign MachineControl Guide for more information.*

Video and Clock Reference


(SD Video Only)

If you have only a single SD (standard definition) video source, you may want to follow the wiring tip below to ensure that you have full functionality in all configurations:

To work with a single SD video source:

- 1** Connect the SD video signal to Video Ref In.
- 2** Run a short BNC jumper cable from the Video Ref Out connector to the Video In connector.
- 3** Connect the Video Out signal to the video input of your destination VTR or video editing system.

The choice of video connector also matters when choosing a positional reference. For instance, when the SYNC HD is in Generate mode and Video is the current clock reference, the time code reference for the generator is always from the Video Ref In connector. However, if you select a positional reference other than Generate, then the signal at the Video In connector can be used.

 *For more video signal information, refer to "Video and VITC Signals" on page 69 in Appendix A.*

Digital Clock

To resolve the SYNC HD to external AES/EBU or Word Clock:

From Pro Tools:

- In the SYNC Setup section of the Session Setup window, select the appropriate digital clock reference from the Clock Reference pop-up menu.

From the front panel:

- 1** Press the Clock Reference switch to select DIGITAL.
- 2** Press Set, and use the Up or Down switches to display Digital Reference (d16 rEF).
- 3** Press Set again. The LED Time Code Display displays the current digital reference, which will be:
 - AES/EBU (AES-E8U)
 - or –
 - Word Clock (I CLOC)
- 4** Press Up or Down to select the digital clock you want to use.
- 5** Press Set.

From the SYNC Setup software utility (Windows only):

- Select the appropriate Digital clock reference option from the Clock Ref pop-up menu.

If the chosen clock reference source is unavailable, or the current configuration is not valid, the Locked LED on the right side of the SYNC HD front panel flashes.

Additional Digital Clock Information

AES/EBU The SYNC HD AES/EBU In connector only recognizes and uses the clock portion of an incoming AES/EBU audio signal. All audio information will be ignored and will not be passed to the SYNC HD AES/EBU Out connector.


Word Clock Word Clock is a digital clock reference signal that runs at 1x sample rate (44.1, 48, 88.2, 96, 176.4, or 192 kHz). Pro Tools|HD interfaces have dedicated BNC-style Word Clock connectors. A wide variety of professional audio devices have Word Clock connectors, including digital mixing consoles, DASH-standard digital multitrack tape recorders and MDMs (modular digital multitrack recorders).

Slave Clock (256x)

Slave Clock (or Super Clock) is a Digidesign proprietary clock format used by legacy Digidesign audio interfaces (such as 888|24, 882|20, 1622, and ADAT Bridge) that runs at 256 times the sample rate.

When using legacy interfaces with SYNC HD and Pro Tools|HD, your master HD audio interface (192 I/O, 192 Digital I/O, 96 I/O, or 96i I/O) should supply Slave Clock to the first legacy device through its External Clock Out connector, configured for 256x Slave Clock (see “Base Clock” on page 60 for more information).

Pro Tools|HD audio interfaces are always connected using Loop Sync (see “Clock for Pro Tools Audio Interfaces” on page 8 for more information).


 For additional digital clock signal information, see “Digital Clock Signal Types” on page 71.

LTC and Clock Reference

LTC can provide both positional and clock information from the same time code signal. LTC cannot be read when the reference deck is stopped, or playing back at slow or fast wind speeds (roughly 10x playback speed). Pro Tools will not lock until the LTC signal is close to playback speed.

While resolving to LTC as clock reference, the SYNC HD provides five options to optimize your system for different types of tasks. This lets you choose between faster response (for when fast lock-up time is critical), or highest sound quality (during critical laybacks, for example).

The Session Setup window provides a sub-menu for LTC Clock Reference choices. The five choices provide different servo gain settings to reduce the effects of jitter when locking to linear time code. In Standalone mode, these settings are also available from the front panel.



Clock Reference LTC options in Session Setup

To resolve the SYNC HD to Linear Time Code from Pro Tools:

- In the Sync Setup section of the Session Setup window, choose an LTC setting from the Clock Reference pop-up menu. Choices include:

LTC 0 (fastest) Allows the quickest resolving to incoming LTC, but with greater jitter. This is the default setting, and should be used when fast lock ups are critical.

LTC 1 Provides an intermediate fast setting.

LTC 2 (average) Offers a compromise of lock up time and jitter quality.

LTC 3 Provides an intermediate slow setting.

LTC 4 (smoothest) Offers the lowest jitter from LTC resolve, but can take six to ten seconds to achieve full resolve. This setting is most appropriate when loading audio from an analog master, where reducing or eliminating jitter is more important than lock speed. Be sure to allow adequate pre-roll before punching in.

To resolve the SYNC HD to Linear Time Code from the front panel:

- Press the Clock Reference switch to select LTC.

To resolve the SYNC HD to Linear Time Code using the SYNC Setup software utility (Windows only):

- Select Linear Time Code (LTC) from the SYNC Setup Clock Ref pop-up menu.



The SYNC HD provides adjustable LTC servo gain. See “Servo Gain” on page 62.

Adjusting LTC Output Level

To adjust LTC output level from Pro Tools:

- 1 Choose Setup > Peripherals and click Synchronization.
- 2 Choose a value from the LTC Output Level pop-up menu.
- 3 Click OK.

To adjust LTC output level from the front panel:

- 1 Press Set until the LED Time Code Display shows a parameter name. The first name is Set Generator (SE7 6En), although you may see a different name, depending on the previous SYNC HD settings.
- 2 Press the Up or Down switches until the LED Time Code Display shows LTC Level (L7C LEUL).
- 3 Press Set. The LED Time Code Display shows the current value for the LTC Output Level (in dBu).
- 4 Press the Up or Down switches to scroll through the available values (in 3 dBu steps).
- 5 Press Set.

Additional LTC Information

LTC can provide positional and clock reference. LTC can be recorded onto and played back from an analog track, or a VTR audio, address or cue track.



For further information on LTC signals, see “LTC Signals” on page 70.

Pilot Tone

The SYNC HD can resolve to an external Pilot Tone signal for clock reference, for synchronizing to (or transferring audio from) certain types of open-reel audio tape recorders. Pilot Tone is basically a 60 Hz (NTSC) or 50 Hz (PAL) sine wave tone. Pilot Tone is used on location film shoots to establish a common sync reference between a film or video camera with a portable 1/4-inch analog ATR. Pilot Tone contains no positional information; it provides only clock reference.

The SYNC HD decides whether to use 60 Hz or 50 Hz as the pilot tone reference frequency according to the setting of the Video Format. When set to PAL, the pilot tone frequency is assumed to be 50 Hz. When set to NTSC, 60 Hz is assumed.

Connect the Pilot Tone reference source to the SYNC HD Bi-Phase/Tach/GPI/Pilot port.

To resolve the SYNC HD to Pilot Tone:

From Pro Tools:

- In the SYNC Setup section of the Session Setup window, select Pilot Tone from the Clock Reference pop-up menu.

From the front panel:

- Press the Clock Reference switch to select PILOT.

From the SYNC Setup software utility (Windows only):

- Select Pilot Tone from the SYNC Setup Clock Ref pop-up menu.



For additional Pilot Tone information, see “Pilot Tone” on page 73 in Appendix A.

Bi-Phase/Tach and Clock Reference

The SYNC HD is able to resolve to Bi-Phase/Tach information for use as a clock reference. Bi-Phase/Tach can synchronize positional reference, but you must provide a reference *start address* (see “Bi-Phase Position Trimming” on page 48 for other requirements). Pro Tools will not lock until the Bi-Phase signal is present.

To configure Bi-Phase/Tach settings, you need to use the SYNC Setup software utility (Windows only) or the SYNC HD front panel controls.

To configure Bi-Phase/Tach for the SYNC HD clock reference:


From the SYNC Setup software utility (Windows only):

- 1 Select Bi-Phase/Tach from the SYNC Setup Clock Ref pop-up menu.
- 2 Select the appropriate Pulse Per Frame and Input Signals parameters, as described in “Bi-Phase/Tach Starting Frame” on page 47 and “Bi-Phase/Tach Signal” on page 47.

Typically, when you use Bi-Phase/Tach as the clock reference you will also be using it as the positional reference (see “Bi-Phase/Tach Positional Reference” on page 46.).


From the front panel:

- 1 Press the Clock Reference switch to select BI-PHASE/TACH.
- 2 Select the appropriate Pulse Per Frame and Input Signals parameters, as described in “Bi-Phase/Tach Starting Frame” on page 47 and “Bi-Phase/Tach Signal” on page 47.

 *If the Bi-Phase/Tach reference clock source is not valid for any reason (such as a poor connection or other signal transmission problem), the Locked LED on the far-right of the SYNC HD front panel will flash. The SYNC HD accepts up to 12 volts at the Bi-Phase input.*

To select Bi-Phase/Tach as the positional reference from Pro Tools:

- 1 In the SYNC Setup section of the Pro Tools Session Setup window, select Bi-Phase from the Positional Reference pop-up menu.
- 2 Set the Pulse Per Frame and Input Signals from the Synchronization page of the Peripherals dialog.

 *For additional Bi-Phase/Tach signal information, see “Bi-Phase/Tach” on page 72 in Appendix A.*

Internal Clock: Generating and Regenerating

The SYNC HD can use its own crystal-referenced internal clock as a master clock source. When SYNC HD Clock Reference is set to Internal:

- Word Clock and AES/EBU digital clock outputs are simultaneously driven from the internal crystal reference.
- and –
- If the Positional Reference is set to Generate, generated LTC, MTC, VITC, and Window Dub outputs are resolved to the same internal crystal reference.

To resolve the SYNC HD to its internal clock:

From Pro Tools:

- In the SYNC Setup section of the Pro Tools Session Setup window, select Internal/VSO from the Clock Reference pop-up menu.

From the front panel:

- Press the Clock Reference switch to select INTERNAL/VSO.

From the SYNC Setup software utility (Windows only):

- Select Internal/VSO from the SYNC Setup Clock Ref pop-up menu.


Variable Speed Override (VSO)

To fine-tune the speed (and pitch) of Pro Tools or any device receiving its clock reference from the SYNC HD, you can varispeed the rate of the SYNC HD crystal-referenced internal clock.

VSO is available at any positional reference setting. VSO is not available from the SYNC HD front panel controls, but can be controlled directly from Pro Tools or with the SYNC Setup software utility (Windows only).

To varispeed the SYNC HD internal clock from Pro Tools:


- 1 In the Sync Setup section of the Session Setup window, make sure the Clock Reference is set to Internal/VSO.
- 2 Select the VSO option.
- 3 Adjust the varispeed value using the on-screen slider.



Variable Speed Override controls (Pro Tools)

To varispeed the SYNC HD internal clock from the SYNC Setup software utility (Windows only):

- 1 In the Setup Variable Speed Override section, select VSO Enabled.



Variable Speed Override controls (SYNC Setup software utility)

- 2 Use the sliders to adjust the varispeed values in semitone or cent increments. The actual output word-clock frequency is shown near the sliders.

– or –

Enter the value in semitones and cents using the editable fields. Varispeed range changes with sample rate, as shown in the following table.

Effective VSO rates

| Sample Rate (kHz) | Rate Type | Min. (Hz) | Max (Hz) |
|-------------------|-----------|-----------|----------|
| 44.1 | 1x | 40000 | 50500 |
| 48 | | | |
| 88.2 | 2x | 80000 | 101000 |
| 96 | | | |
| 176.4 | 4x | 160000 | 202000 |
| 192 | | | |

The SYNC HD will only output rates within the limits of the current sample rate. If a varispeed value results in an output frequency (sample rate) that is below or above the limits for the current sample rate, the frequency display turns red.

- 3 Click Set.

Using Pitch Memory

Pitch Memory holds the output sample rate steady even when the Clock Reference is unavailable or has gone out of lock range.

- ◆ When Pitch Memory is not enabled, the output sample rate would return to the nominal sample rate setting (for example, exactly 44.1 kHz) when the Clock Reference disappears or goes out of lock range.
- ◆ When Pitch Memory is enabled, Pro Tools continues to play and record at the resolved sample rate even if the Clock Reference source disappears.

To configure Pitch Memory:

From Pro Tools:

- 1 Choose Setup > Peripherals and click Synchronization.
- 2 Select the Pitch Memory Enabled option.
- 3 Click OK.

From the front panel:

- 1 Press Set, and use the Up or Down switches to display Pitch Hold (PICH HLD).
- 2 Press Set. The LED Time Code Display shows On or Off.
- 3 Press Up and Down to toggle between On and Off.
- 4 Press Set.

From the SYNC Setup software utility (Windows only):

- Click Pitch Memory Enabled.

The SYNC HD retains the Pitch Memory setting, even when the unit is powered off and on again, until you change it.

Positional Reference and Options

The following sections provide additional information for each available Positional Reference format.

Linear Time Code (LTC)

LTC is often striped onto an ATR or VTR audio track. Professional VTRs typically have an address or cue track, intended for LTC. If you are working with a standard audio tape, you'll almost certainly be working with LTC. If you're working with a videotape, you may be able to work with either LTC or VITC, or both.

LTC can also be generated as an interpolation of Absolute code. This is how time code DAT machines, DA-88, and many digital VTRs work. In any case, LTC is delivered to the SYNC HD as a series of audio pulses, regardless of how it is stored or generated.

LTC can function simultaneously as a positional reference and a clock reference.

To use LTC as the SYNC HD positional reference:

From Pro Tools:

- In the SYNC Setup section of the Session Setup window, choose LTC from the Positional Reference pop-up menu.

From the front panel:

- Press the Positional Reference switch to select LTC.

From the SYNC Setup software utility (Windows only):

- Select Linear Time Code (LTC) from the SYNC Setup Positional Ref pop-up menu.

Make sure you select the appropriate clock reference, sample rate, frame rate, and freewheel duration. Also make sure the LTC signal is routed properly to the SYNC HD LTC In connector.

Freewheel Duration

Freewheel duration (time code freewheel) configures the SYNC HD for a maximum number of frames it should continue generating if time code drops out or is otherwise interrupted. Freewheel settings are ignored when the SYNC HD is in Internal/Generate mode.

Example of Time Code Freewheel

In a 30 fps Pro Tools session, if Freewheel Duration/Time Code Freewheel is 28 frames, the SYNC HD will continue to generate until either the incoming time code signal is restored, or until 28 frames elapse, whichever occurs first.

To set the freewheel duration:

From Pro Tools:

- In the Time Code Settings section of the Session Setup window, enter a number of frames for time code Freewheel.



SYNC HD accepts Freewheel duration values from 4 to 40 frames, in increments of 4 frames, but Pro Tools allows duration values from 1 to 120 frames (for MTC readers). If you enter a Freewheel durations value lower than 4, the SYNC HD will automatically set to 4; if you enter a Freewheel value greater than 40, SYNC HD will automatically set to 40.

From the front panel:

- 1 Press Set, and use the Up or Down switches to display Freewheel Length (FrEE LEN).
- 2 Press Set to display freewheel duration choices.

- 3 Use the Up or Down switches to scroll through available choices (lowest is “4 Fr” or four frames, highest is “40 Fr” or 40 frames).

- 4 Press Set.

From the SYNC Setup software utility (Windows only):

- Choose a value from the Freewheel Duration menu.

VITC and Positional Reference

VITC is a commonly used positional reference in professional audio post-production. Since VITC is time code information that is embedded as part of the video signal, VITC can be read when the VTR is paused or crawling slowly. When working with Pro Tools, this means that VITC can be used for Auto-Spotting regions to particular video frames.

VITC is less prone to tape drop outs, and in this sense, is inherently more reliable than LTC. VITC can be embedded into any video signal, including digital video signals (tape or nonlinear), without requiring an extra audio track to carry time code.

Tape Protection Mode and VITC

In order for VITC to be read when a videotape is paused, the picture must remain visible. However, to reduce wear on the video heads, after a few minutes of still/pause mode, many VTRs will automatically drop into stop mode—which means the tape will be disengaged from the heads, and VITC can no longer be read off the tape. To continue reading VITC, you may need to reengage still/pause, or press play and re-shuttle the tape to the desired frame.

Clock Considerations for VITC

To avoid tape protection mode problems and ensure constant clock referencing, use the Video Ref In as your clock reference instead of Video In, whenever possible. When using Video Ref In (and house sync), if the video picture disappears the SYNC HD will remain resolved to the black burst signal at the Video Ref In connector.

To use VITC as the SYNC HD positional reference:

From Pro Tools:

- In the SYNC Setup section of the Session Setup window, select VITC from the Positional Reference pop-up menu.

From the front panel:

- Press the Positional Reference switch to select VITC.

From the SYNC Setup software utility (Windows only):

- Select Vertical Interval Time Code (VITC) from the SYNC Setup Positional Ref pop-up menu.

Additional VITC-Related Settings

SYNC HD Settings Make sure to set the appropriate clock reference, sample rate, frame rate, and freewheel duration.

Connections and Sources Make sure that your VITC-striped video signal, if any, is routed to the SYNC HD Video In connector (not the Video Ref In connector). If you use a black burst signal as clock reference connect it to the Video Ref In connector.

You should consider using Video Ref as your Clock Reference (rather than Video In) when working with VITC because a black-burst signal at the Video Ref input will always be there, unlike the video signal at Video In, which may disappear if the videotape disengages.

Auto Switch LTC/VITC Positional Reference

In Auto Switch mode, the SYNC HD switches automatically between LTC and VITC depending upon which is delivering the best time code signal. This is indicated on the front panel by the LTC and VITC positional reference LEDs (both will be lit), and by a decimal point between the minutes and seconds. on the front panel time code display.

VITC cannot be read at high speeds (shuttle speeds, for example) while LTC can, and LTC cannot be read at slow speeds (while VITC can be read at slow speeds, and when parked). Auto Switch LTC/VITC provides the best of both LTC and VITC reading without having to manually switch settings.

Auto Switch LTC/VITC Requirements

- Make sure the LTC signal is routed properly to the SYNC HD LTC In connector.
- Make sure the VITC-striped video signal is routed properly to the SYNC HD Video In connector (not the Video Ref In connector).
- Make sure to have or stripe matching code on both your LTC and VITC tracks (and your on-screen video window burn, if any).
- Make sure to select Auto or the correct line pair for VITC Read.
- Make sure to select the appropriate clock reference, sample rate, frame rate, and freewheel duration options.

- If the same tape has different values for LTC and VITC signals, make sure to run only against LTC by disabling Auto LTC/VITC. Otherwise, Pro Tools may locate to different places depending on whether the tape is static or playing back.

To select Auto Switch LTC/VITC for positional reference:

From Pro Tools:


- In the SYNC Setup section of the Session Setup window, select Auto Switch (LTC/VITC) from the Positional Reference pop-up menu.

From the front panel:

- Press the Positional Reference switch to select Auto Switch LTC/VITC (indicated when both the LTC and VITC LEDs are simultaneously lit).

From the SYNC Setup software utility (Windows only):

- Select Auto Switch LTC/VITC from the SYNC Setup Positional Ref pop-up menu.

 For additional information and examples of Auto Switch LTC/VITC, see “Auto-Switch LTC/VITC” on page 70 in Appendix A.

Serial Time Code

The SYNC HD provides two 9-pin ports, to be used with MachineControl-enabled systems to remotely control, or follow, external 9-pin transports through the use of serial time code.

For MachineControl-equipped Pro Tools systems, serial time code from either 9-pin port can be used for positional reference. This option is configured from the Peripherals dialog. For details on using serial time code with the SYNC HD, see the *MachineControl Guide*.

Bi-Phase/Tach Positional Reference

Bi-Phase/Tach signals are clock reference signals, and do not contain positional information of their own. However, they do contain enough information for the SYNC HD to calculate positional information.

To calculate positional reference from Bi-Phase/Tach requires that the SYNC HD be given a starting frame address, and a specific pulses-per-frame value. Each of these related settings are explained in the following sections.

To use Bi-Phase/Tach for positional reference:

First, do one of the following:

From Pro Tools:

- In the SYNC Setup & Time Code Offsets section of the Session Setup window, select Bi-Phase from the Positional Reference pop-up menu.

From the front panel:

- Press the Positional Reference switch to select BI-PHASE.

From the SYNC Setup software utility (Windows only):

- Select Bi-Phase/Tach from the SYNC Setup Positional Ref pop-up menu.

Continue by setting the starting frame as described in “Bi-Phase/Tach Starting Frame” on page 47, and setting other Input Signals options, as appropriate.

Bi-Phase/Tach Starting Frame

In order to use the Bi-Phase/Tach signal as a positional reference, the SYNC HD also needs to know the time code address for a particular frame of film. This positional relationship is established by parking the film device at a particular frame and setting the SYNC HD to the equivalent time code value using the Bi-Phase/Tach Starting Frame parameter.

To set the Bi-Phase/Tach start frame from Pro Tools:

- 1 In Pro Tools, place the playback cursor at the desired time code location.
- 2 Choose Setup > Peripherals and click Synchronization.
- 3 Click the Reset Bi-Phase button.

The Time Code Display on the SYNC HD updates to match the session time code value.

To set the Bi-Phase/Tach start frame from the front panel:

- 1 Press Set, and use the Up or Down switches to display Set Gen (SE7 6En).
- 2 Press Set to display time code numbers. One of the time code fields (hours:minutes:seconds:frames) flashes.
- 3 Press the Up or Down switch to scroll through the parameter values.
- 4 To set a time code setting and advance to the next field, press and release the Down and Up switches simultaneously.
- 5 Repeat until you have finished setting the SYNC HD to the desired generator start time.
- 6 Press Set.

The LED Time Code Display stops flashing, and displays the start time.

To set the Bi-Phase/Tach start frame using the SYNC Setup software utility (Windows only):

- 1 In the Generator/Bi-Phase Preset section, type in the time code value of the starting frame, in hours:minutes:seconds:frames.
- 2 Click Set.

Bi-Phase/Tach Signal

The Bi-Phase/Tach signal can be set to any of the following:

Bi-Phase: FWD = A leads B When the A square wave is ahead of the B square wave, the direction of the Bi-Phase signal is understood to be “Forward.”

FWD = B leads A When the B square wave is ahead of the A square wave, the direction of the Bi-Phase signal is understood to be “Forward.”

Tach: FWD = B is Low When the B signal is in a “low” state, the rate and direction (“r-n-d”) of the Tach signal is understood to be “Forward.”

Tach: FWD = B is High When the B signal is in a “high” state, the rate and direction (“r-n-d”) of the Tach signal is understood to be “Forward.”

To define the direction for a Bi-Phase/Tach input signal from Pro Tools:

- 1 Choose Setup > Peripherals and click Synchronization.
- 2 Choose one of the following settings from the Bi-Phase/Tach Wiring pop-up menu:
 - Bi-Phase: FWD = A leads B
 - Bi-Phase: FWD = B leads A
 - Tach: FWD = B is Low
 - Tach: FWD = B is High
- 3 Click OK.

To define the direction for a Bi-Phase/Tach input signal using the front panel controls:

- 1 Press Set, and use the Up or Down switches to display Bi-Phase/Tach Input Signal (bIPH 516).
- 2 Press Set. The LED Time Code Display shows one of the four parameter values:
 - “A LEAd b”: Bi-Phase: FWD = A leads B
 - “b LEAd A”: Bi-Phase: FWD = B leads A
 - “r-n-d LO”: Tach: FWD = B is Low
 - “r-n-d HI”: Tach: FWD = B is High
- 3 Use the Down and Up switches to scroll between the parameter values.
- 4 Press Set.

To define the direction for a Bi-Phase/Tach input signal using the SYNC Setup software utility (Windows only):

- 1 In the Bi-Phase/Tach Parameters section, choose one of the following settings from the Wiring pop-up menu:
 - Bi-Phase: FWD = A leads B
 - Bi-Phase: FWD = B leads A
 - Tach: FWD = B is Low
 - Tach: FWD = B is High
- 2 Click Set.

Bi-Phase/Tach Pulses-per-frame (PPF)

There are several different standards for the number of pulses-per-frame output by Bi-Phase or Tach devices. You can set the SYNC HD to operate from 2 to 254 pulses per frame from Pro Tools, from the SYNC HD or using the SYNC Setup software utility’s Pulse Per Frame setting (Windows only). The setting should match the PPF rate of the external device’s Bi-Phase/Tach encoder.

To set the pulses per frame value for a Bi-Phase/Tach signal from Pro Tools:

- 1 Choose Setup > Peripherals and click Synchronization.
- 2 In the Bi-Phase/Tach Pulses/Frame field, enter a value from 2 to 254.
- 3 Click OK.

To set the pulses per frame value for a Bi-Phase/Tach signal using the front panel:

- 1 Press Set, and use the Up or Down switches to display Bi-Phase/Tach Pulses Per Frame (bIPH PPF).
- 2 Press Set. The LED Time Code Display will switch to display the current PPF value.
- 3 Use the Down and Up switches to scroll through the parameter values (from 2 to 254 pulses per frame). Holding either switch will scroll at a faster speed.
- 4 Press Set.

To set the pulses per frame value for a Bi-Phase/Tach signal using the SYNC Setup software utility (Windows only):

- 1 In the Bi-Phase/Tach Parameters section, enter a value from 2 to 254 in the Pulses/Frame field,
- 2 Click Set.

Bi-Phase Position Trimming

While using bi-phase as your positional reference, you can trim the Bi-Phase-to-time code translation at any time. Each press of the Up switch will advance the time address one frame. Each press of the Down switch will retard the time address by one frame. Remember how many presses you’ve accumulated so that you can go back and trim the starting address you previously programmed.

Compensating for Time Code Offsets

You can offset the display of incoming time code in the Pro Tools application. This is useful when you want to adjust the display of time code to match the start time of the session (such as with source material that starts at a different time), or compensate for source material that is consistently offset by a fixed number of frames (such as with some color-corrected video masters).

Pro Tools provides four different types of External Time Code Offset settings. These offsets include:

- MMC (MIDI Machine Control)
- 9-Pin (Deck Control)
- Synchronization peripherals such as the SYNC HD, SYNC I/O, or other peripherals (such as MIDI interfaces that provide MIDI Time Code).
- Video Satellite (Pro Tools with Avid Media Station|PT)

Unique values can be defined for each of these types of offsets, or you can link all to adjust in unison.

Positive and negative offset values can be entered to offset Pro Tools time code display later or earlier, respectively.

Offsets and SYNC HD Time Code Display

The SYNC HD front panel display continues to display actual incoming time code, regardless of any External Time Code Offsets settings that are applied in Pro Tools.

To apply an offset to the external time code settings:

- In the Session Setup window, in the External Time Code Offsets section, enter a time in an offset field.


To apply the same external time code to all devices:

- In the Session Setup window, select Link to apply the same offset value to all devices.

Generating & Regenerating Time Code

The SYNC HD generates LTC, VITC, and MTC simultaneously, obtaining time addresses from a variety of sources:

- When the Positional Reference is set to Generate, the SYNC HD generates LTC, VITC, and MTC from an internal time address clock. This is referred to as Generator Preset mode.
- When the Positional Reference is LTC, VITC, or Bi-Phase, the SYNC HD generates LTC, VITC, and MTC based on the time address of one of those sources. This is sometimes called *regeneration* or *translation*. For the SYNC HD, this is referred to as Read/Regeneration mode.

 *Time code generated by the SYNC HD does not follow session Pull Up and Pull Down settings.*

Read/Regeneration Mode


In this mode, the SYNC HD regenerates time code based on external positional reference information (LTC or VITC time code, or a Bi-Phase/Tach signal). Subject to certain conditions, three types of time code (LTC, VITC, and MTC) are simultaneously regenerated from the selected positional reference.

Requirements for Read/Regeneration of LTC, VITC and MTC

LTC The external positional reference must be moving at normal, 1x forward speed ($\pm 8\%$).

VITC The positional reference must be LTC or Bi-Phase/Tach, at any readable speed, forward or reverse, or when the positional reference is set to Generate. The SYNC HD will not regenerate VITC if the positional reference is VITC.

MTC In order for the SYNC HD to regenerate continuous MTC, the external positional reference must be moving at normal, 1x forward speed ($\pm 8\%$). Outside of this speed range and direction, MTC is generated in bursts every 200 milliseconds. This allows MTC-slaved devices to read VITC or Bi-Phase properly in either direction, and at speeds down to zero. The SYNC HD begins regenerating MTC as soon as it again detects a valid positional reference signal.

 *To optionally mute idle time MTC output, see “MTC Output and Idle Muting” on page 56.*

If the positional reference is LTC or VITC, the SYNC HD will regenerate time code addresses that match the incoming time code addresses. If the positional reference is a Bi-Phase/Tach signal, the SYNC HD will generate time code addresses starting at the Bi-Phase preset start time. (See “Bi-Phase/Tach Starting Frame” on page 47 for more information.)

Generator Preset Mode

In this mode, the SYNC HD generates time code internally from a start time based upon the Generator Preset Time. Using either the SYNC Setup software utility (Windows only) or the SYNC HD front panel controls, you can start, stop, resume, and reset time code generation.

When generating time code in Generator Preset Mode, the SYNC HD time code generator is resolved (locked) to one of three possible sources, based upon the following Generator Reference rule.

Generator Reference Rule

◆ If the Clock Reference is set to Internal, LTC, Pilot Tone, Bi-Phase/Tach, Digital (AES/EBU), or Digital (Word Clock), then the time code generator will lock to the selected clock reference.

– or –

◆ If the Clock Reference is set to one of the two video inputs (Video Ref In or Video In), then the time code generator will reference the Video Ref In connector.

Frame Rate Restrictions with Video Reference

In Generator Preset mode, if the Clock Reference is set to one of the two video inputs (Video Ref In or Video In), Pro Tools is restricted to generating time code at the incoming video frame rate.

With the SYNC HD, the Time Code Rate you choose is dependent on the video format:

- For NTSC, you can choose only 29.97 FPS or 29.97 FPS DROP.
- For PAL, you can choose only 25 FPS.

In Generator Preset mode, if the Clock Reference is set to one of the two video inputs, 24 fps cannot be used as the SYNC HD time code format.

These restrictions are removed when not in Generator Preset mode.

Generator Start Time

To set the generator start frame:

From Pro Tools:

- Configure the Session Setup window as appropriate for your system and the current project. Refer to the *Pro Tools Reference Guide* for specific instructions.

From the front panel:

- 1** Press Set, and use the Up or Down switches to display Set Gen (SE7 6En).
- 2** Press Set. One of the time code fields displayed will be flashing.
- 3** Press Up or Down to lower or raise the currently flashing value.
- 4** To set a time code setting and advance to the next field, press and release Down and Up simultaneously.
- 5** Repeat until you have finished setting the SYNC HD to the desired generator start time.
- 6** Press Set.

The SYNC HD retains the setting, even when the unit is powered off and on again, until you change it.

LTC Generation/Regeneration

Regenerating LTC

The SYNC HD will regenerate LTC whenever the external positional reference is moving at normal, 1x forward speed ($\pm 10\%$).

Make sure LTC is correctly routed as explained in Chapter 2, “Installation and Configuration”. If you need to adjust the level of the SYNC HD LTC output signal, see “Adjusting LTC Output Level” on page 39. You can also adjust the SYNC HD LTC servo gain, as described in “Servo Gain” on page 62.

To regenerate LTC:

From Pro Tools:

- In the Sync Setup section of the Session Setup window, select any external positional reference (except Generate).

From the front panel:

- Press the Positional Reference switch to select an external positional reference (do not select GENERATE).

From the SYNC Setup software utility (Windows only):

- Select an external positional reference from the SYNC Setup Positional Ref pop-up (except Generate).

The SYNC HD regenerates LTC as soon as it receives a valid positional reference signal.

Generating LTC

In Generator Preset mode, the SYNC HD can generate LTC using either an external or internal clock reference. Make sure LTC is correctly routed and that all your other gear is properly configured before you begin. If necessary, adjust the input level for the destination device.

To generate LTC using Pro Tools:

- 1 In the Time Code Settings section of the Session Setup window, select Using SYNC under Generator.
- 2 Put Pro Tools online.
- 3 Start Pro Tools recording or playback. Pro Tools commands the SYNC HD to begin generating LTC with time addresses synchronized to the session time line.

To generate LTC using the front panel controls:

- 1 Press the Positional Reference switch to select GENERATE.
- 2 Configure the desired time code start in hours:minutes:seconds:frames using the Set, Up and Down switches. See “Generator Start Time” on page 51 for instructions.
- 3 To begin generating, press and release the RUN/STOP/CLEAR/ESC switch.

To generate LTC using the SYNC Setup software utility (Windows only):

- 1 Select Generate in the Positional Ref pop-up menu.
- 2 In the Generator/Bi-Phase Preset window (time fields), type in the desired time code start time, in Hrs:Min:Sec:Frm. To reset, click Zero.
- 3 To begin generating, click Run.
- 4 When you have finished generating the desired length of LTC, click Stop.

VITC Generation/Regeneration

When you use the SYNC HD to regenerate or generate VITC, you'll be inserting VITC into an existing video signal. The input is derived according to the following rule.

VITC Video Source Rule

Since the SYNC HD has two video inputs ("Video In" and "Video Ref In"), the following rule describes which of these two signals VITC is applied to.

- ◆ If the Positional Reference is set to Generate *and* the Clock Reference is set to either of the two video inputs, then VITC will be applied to the video signal at the Video Ref In connector and fed to the Video Out connector.
- ◆ Under all other combinations of Positional Reference and Clock Reference, VITC will be applied to the video signal at the Video In connector and fed to the Video Out connector.

In addition, the SYNC HD will not insert new VITC while reading VITC from an external source. This is a safety feature to prevent the loss of existing VITC in the video stream. VITC is never inserted when the Positional Reference is set to VITC or Auto Switch LTC/VITC.

Example Video Input Configuration

One common situation is transferring video from a source VTR (or a nonlinear video editing system) to a destination VTR (or a nonlinear video editing system). The video source signal is connected to one of the SYNC HD video input connectors according to the VITC Video Source rule.

The SYNC HD Video Out signal is connected to the destination device. The SYNC HD is then able to stripe the second VTR's videotape with VITC. (At the same time, you might also want to insert a window burn. See "Window Dub Display Options" on page 58.)

▲ *Unlike LTC, the SYNC HD can regenerate VITC with both forward and reverse time code addresses.*

To prevent destruction of the original VITC code, the SYNC HD will not re-apply (regenerate) VITC onto the same video stream from which it is reading VITC.

LTC If you want to use LTC as a positional source, do not select Auto Switch LTC/VITC.

External In order for the SYNC HD to regenerate VITC based on an external positional reference, you'll need to select both a clock reference and a positional reference.

To regenerate VITC based on an external positional reference from Pro Tools:

- 1** Ensure that the SYNC HD is connected in-line with a video source and video destination.
- 2** Ensure that VITC Insertion Enabled is selected in the Synchronization page of the Peripherals dialog.
- 3** If necessary, choose the line pair from the VITC Generate Lines pop-up menu in the in the Synchronization page of the Peripherals dialog.
- 4** In the SYNC Setup section of the Session Setup window, select valid clock and positional references, and ensure that you have selected the appropriate video format (NTSC or PAL, depending on your project). For instructions, see "Video Format/System" on page 63.

The SYNC HD will regenerate VITC and insert it onto the video signal (as soon as it receives a valid clock reference signal and positional reference signal).

To regenerate VITC based on an external positional reference from the front panel:

- 1** Connect the video source to the SYNC HD Video Ref In connector and loop to the SYNC HD Video Input connector.
- 2** Press Set, and use the Up or Down switches to display VITC Insertion (VI7C In5).
- 3** Press Set.
- 4** Use the Down and Up switches toggle between On and Off.
- 5** Press Set to select VITC Insertion.
- 6** Ensure that you have selected the appropriate video format (NTSC or PAL).
- 7** Press Set, and use the Up or Down switches to display VITC Generate Lines (6En LInE).
- 8** Press Set. The default line pair is 14/16, which is also the SMPTE-recommended setting.
- 9** Use the Down and Up switches to scroll through the parameter values and select a VITC line pair.
- 10** Press Set. The LED Time Code Display will return to showing time code numbers.
- 11** Select valid clock and positional references.

The SYNC HD will regenerate VITC and insert it onto the video signal (as soon as it receives a valid positional reference signal).

To regenerate VITC based on an external positional reference using the SYNC Setup software utility (Windows only):

- 1** Ensure that the SYNC HD is connected in-line with a video source and video destination.
- 2** Ensure that VITC Insertion Enabled is checked in the SYNC Setup window and that you have selected the appropriate video format (NTSC or PAL).
- 3** Use the VITC Generate Lines menu to configure the line pair, if necessary.
- 4** Select the appropriate clock reference.
- 5** Select either LTC or Bi-Phase/Tach from the SYNC Setup Positional Reference pop-up menu:

Internal VITC Generation

The SYNC HD can also generate VITC internally, using its integral time code generating feature. In this mode (Positional Reference switch = Generate) you can use either an external clock reference, or the SYNC HD internal crystal as a clock reference with a variable start time.

When generating VITC internally, if the insertion is not timed based upon an *upstream* video reference you may encounter repeated or skipped VITC frames. Be sure to check “VITC Timing Rule” on page 69 and “VITC Video Source Rule” on page 53.

To generate VITC using Pro Tools:

- 1** Ensure that the SYNC HD is connected in-line with a video source and video destination.
- 2** In the Time Code Settings section of the Session Setup window, select Using SYNC under Generator.
- 3** Ensure that VITC Insertion Enabled is selected in the Synchronization page of the Peripherals dialog.
- 4** If necessary, choose the line pair from the VITC Generate Lines pop-up menu in the Synchronization page of the Peripherals dialog.
- 5** In the SYNC Setup section of the Session Setup window, select a valid clock reference and ensure that you have selected the appropriate video format (NTSC or PAL, depending on your project). For instructions, see “Video Format/System” on page 63.
- 6** Put Pro Tools online.
- 7** Start Pro Tools recording or playback. Pro Tools commands the SYNC HD to begin generating VITC with time addresses synchronized to the session time line.

To generate VITC internally using the front panel controls:

- 1** Ensure that the SYNC HD is connected in-line with a video source and video destination.
- 2** Press Set, and use the Up or Down switches to display VITC Insertion (VITC In5). For detailed instructions, see “VITC Insertion” on page 60.
- 3** Use the Down and Up switches to toggle VITC Insertion On and Off.
- 4** When On is selected, press Set.
- 5** Press Set, and use the Up or Down switches to display VITC Generate Lines (6En LInE).

6 Press Set. The default line pair is 14/16, which is also the SMPTE-recommended setting.

7 Use the Down and Up switches to scroll through the parameter values and select a VITC line pair.

8 Press Set.

9 Using the Positional Reference switch, select Generate.

10 Set the time code start time. See “Generator Start Time” on page 51 for instructions.

11 Arm the destination VTR to record video, so that VITC can be inserted into the video signal, and be recorded on the destination videotape.

12 Make sure that your chosen clock reference is actually present and running, then press the SYNC HD Run switch.

The time code addresses will begin to increment.

To pause or stop VITC from the front panel:

- Press and release the Run/Stop/Clear switch when you want to pause or stop the generating process.

To generate VITC Internally using the SYNC Setup software utility (Windows only):

1 Ensure that the SYNC HD is connected in-line with a video source and video destination.

2 Ensure that VITC Insertion Enabled is selected in the SYNC Setup window, and that you have selected the appropriate format (NTSC or PAL).

3 If necessary, select onto which line pair you’ll be generating VITC using the VITC Generate Lines pop-up menu.

4 Select the appropriate clock reference, using SYNC Setup’s Clock Ref selector.

5 From the Positional Ref selector, select Generate.

6 In the Generator/Bi-Phase Preset window, type in the desired time code start time, in Hrs:Min:Sec:Frm. To reset to 00:00:00:00, click Zero.

7 Click Set. Typically, at this point you would arm the destination VTR to record video, so that VITC can be inserted into the video signal, and be recorded on the destination videotape. Make sure that your chosen clock reference is actually present and running, and that it is synchronized with the incoming video signal.

8 Click Run to start. The time code addresses will begin to increment.

9 Click Stop when you want to pause or stop the generating process.



Regardless of whether you are generating or regenerating, an active video signal will need to be present at one of the SYNC HD video inputs. Check to see if the machine is paused, stopped or unlaced.

MTC Generation/Regeneration

MTC (MIDI Time Code) is a serial digital signal. In many ways, you can think of it as an inaudible type of LTC that can be used by various MIDI devices.

MTC is available from the SYNC HD MTC Out connector, which is a standard DIN-style 5-pin female MIDI connector.

To use MTC, connect MTC Out to a MIDI In connector of a device that can recognize and use MTC. Typically, this would be a console, sequencer, synthesizer or sampler keyboard, a drum machine or other device.

MTC Output and Idle Muting

MTC is normally output whenever LTC is output. Whenever LTC output stops, the SYNC HD will continue to output MTC in bursts of one frame every 200 milliseconds. This allows any connected MIDI-reading device to be continuously updated as to the position of VITC or Bi-Phase (either of which might be operating at slow or still speeds). Thus, you can still use a connected MIDI device for Auto-Spotting from VITC or Bi-Phase.

Optionally, this constant output can be set to mute when time code (LTC) is idle.

To mute idle-time MTC output:

From Pro Tools

- 1 Choose Setup > Peripherals and click Synchronization.
- 2 Select the Idle MTC Enabled option.
- 3 Click OK.

From the front panel:

- 1 Press the Set, Up and Down switches to display Idle MTC (Idle 7C).
- 2 Press Set to display the current state (On or Off).
- 3 Press Up or Down to toggle the Idle MTC setting.
- 4 Press Set.

From the SYNC Setup software utility (Windows only):

- 1 Launch the SYNC Setup.
- 2 Deselect the Idle MTC Enabled option.

Generating a Window Dub

The SYNC HD offers time code character generation. This superimposes onto an SD video signal a small area called a *window dub* (or *window burn*, or *time code window*) that displays time code in hours:minutes:seconds:frames.

A window dub provides a visual cue to your location in a project, and can be helpful when spotting regions to video frames in Pro Tools, especially if your only time code reference from tape is LTC (Auto-Spot requires VITC).

The SYNC HD character generator obtains its time code address from the chosen Positional Reference.

Window Dub Requirements

Existing Video Signal The SYNC HD can only insert a time code window into an existing SD video signal. This means that at least one video “source” signal (from a VTR, nonlinear editing system, or other video device) must be present at one of the SYNC HD video input connectors (Video In or Video Ref In). When generating a window dub, the VITC Timing Rule applies (see “VITC Timing Rule” on page 69).


SYNC HD Output The signal from the SYNC HD Video Out connector must be routed to a video destination such as another VTR or nonlinear editing system.

To insert a time code window into a video signal using Pro Tools:


- 1 Choose Setup > Peripherals and click Synchronization.
- 2 Select Enable SYNC Peripheral to make the Window Dub controls available.
- 3 Select Enable Dub Window.

4 Configure any of the following Window dub appearance settings from the corresponding pop-up menu: Vertical Position, Horizontal Position, Size, and Color.

Vertical Position Sets the vertical position of the window dub, relative to the bottom of the video picture. The choices range from 10% From Bottom to 50% From Bottom, in 10% increments.

 *“10% from Bottom” vertical position is outside the standard “safe title” area, which means it may not be visible on some video monitors.*

Horizontal Position Sets the window dub’s relative horizontal position within the video picture. The choices include Extreme Left, Left, Center, Right and Extreme Right.

 *The “Extreme” horizontal positions are outside the standard “safe title” area, which means they may not be visible on some video monitors.*

Size Sets the relative size of the window dub (Small or Large).

Color Sets the color of the time code numbers in the window dub, and the color of the window dub’s background. The choices include White on Black Bkgnd; Black on White Bkgnd; White on Video Bkgnd; or Black on Video Bkgnd. (Video Bkgnd means that the window dub’s background is transparent, so that the time code numbers are displayed directly on top of the video signal, without a contrasting background box.) The default setting is White on Black Bkgnd.

5 Click OK.


To insert a time code window into a video signal using the front panel controls:

- 1 Press Set, and use the Down and Up switches to display Burn Enabled (burn EnA).
- 2 Press Set. The LED Time Code Display will switch to display the current On or Off setting for Window Burn.
- 3 Use the Down and Up switches to switch between the parameter values.
- 4 Press Set.

Based on the selected positional reference, the time code character generator burns time code addresses onto any video signal passing through the SYNC HD.

Window Dub Display Options

If you need to change the appearance of the window dub—in terms of size, vertical position, horizontal position, and color—you need to use Pro Tools or SYNC Setup software utility (Windows only). These parameters cannot be adjusted from the SYNC HD front panel controls.

 *Default Window Dub settings are listed in “Restoring Factory Settings” on page 66.*

To insert a time code window into a video signal using SYNC Setup (Windows only):

- 1 In the Dub Window section of SYNC Setup, select Window Enabled.
- 2 Specify the appearance of the window dub with the pop-up menus for Vertical Position, Horizontal Position, and Color.

Additional Operational Information

Front Panel Generator/Parameter Controls

This section details the parameters available from the multi-function SET, UP, DOWN and RUN/STOP, CLEAR switches (referred to as Set, Up, Down and Run) on the SYNC HD front panel. For details on the multi-function Generator/Parameter switches, see “Front Panel Generator/Parameter Switches” on page 35.

Parameters

SYNC HD parameters are selected and edited using the four Generator/Parameter switches.

To select SYNC HD front panel parameters:

- 1 Press Set.
- 2 Use the Up and Down switches to scroll through available parameters, described below.

The 7-segment LEDs in the Generator/Parameter Display abbreviate some parameter names using numerals to represent letters (such as “5” to represent “S” or “s”). The following table identifies each of these abbreviations.

SYNC HD front panel display of parameter names

| LED | Parameter |
|------------|---------------------------------|
| SE7 6En | Set Generator Start Time |
| dl6 rEF | Digital Reference |
| SPL FrEC | Sample Freq (Rate) |
| PuLL r7E 1 | Pull Up/Down 0.1% |
| PuLL r7E4 | Pull Up 4.167%, Down 4.0% |
| bASE CLOC | External Clock Out |
| VI7C InS | VITC Insertion |
| rdr LInE | (VITC) Reader Line |
| 6En LInE | (VITC) Generate Line |
| burn EnA | Window Burn On/Off |
| FrEE LEn | Freewheel Duration |
| L7C LEUL | LTC Output level |
| SErVo Gn | LTC Servo gain |
| PICH HLd | Pitch Hold On/Off |
| bIPH PPF | Bi-Phase Pulse-per-frame |
| bIPH SI6 | Bi-Phase Signal Configuration |
| VIdEO SY | Video Format (NTSC/PAL) |
| Hd VIdEO | HD Video Format |
| IdLE 7C | Idle MTC On/Off |
| dEviC id | Device ID (SYNC HD or SYNC I/O) |

Set Generator Start Time

Lets you set a start time for the SYNC HD time code generator.

SE 7 6En

See “Generator Start Time” on page 51.

Digital Clock Reference

The SYNC HD can use AES/EBU or Word Clock (1x) for digital clock reference.

d16 rEF

See “Digital Clock” on page 37.

Sample Rate

Selects the SYNC HD sample rate.

SPL FrEE

See “Sample Rate” on page 17.

Pull Rate

Two Pull Rate settings enable 0.1%, and 4%, Pull Up or Pull Down for the current sample rate.

PULL r7E


Pull Rate1 Lets you enable 0.1% pull up or down.

Pull Rate4 Lets you enable 4.167% pull up, or 4.0% pull down, when available.

Base Clock

Configures the Word Clock Out port. Choices are Session (1x the base session sample rate), or 256x (for Slave Clock devices).

BASE CLOC

 *The base sample rate is 44.1 kHz when session sample rate is 44.1, 88.2, or 176.4 kHz, or 48 kHz when session sample rate is 48, 96, or 192 kHz.*

VITC Insertion

When selected, VITC will be inserted onto the outgoing video signal—assuming that a video signal is present at one of the SYNC HD video inputs, and that the SYNC HD is in a valid mode for inserting VITC.

VITC InS

To configure the SYNC HD to insert VITC using the front panel:

- 1 Select VITC Insertion (VITC InS) using the Set, Down, and Up switches.
- 2 Press Set again. The Time Code Display shows On or Off.
- 3 Use Down and Up to toggle the choices.
- 4 Press Set when the desired choice is shown.

VITC Read Lines

This setting determines which line pair of incoming video is used for the VITC source.

rdr L InE

To choose the VITC read lines:

- 1 Select VITC Read Lines (rdr LInE), using the Set, Down, and Up switches.
- 2 Press Set. The Time Code Display will show one of the parameter values:
 - Auto (ALL-LInE)—where the SYNC HD will search all lines and select the first valid line pair automatically
 - The currently selected read lines, if different.
- 3 Use Down and Up to scroll parameters.
- 4 Press Set.

VITC Generate Lines

This setting determines the line pair of the video signal at the Video Out connector onto which the SYNC HD inserts VITC. Normally, this should be left at the default setting of 14/16.



To choose the VITC generate lines:

- 1 Select VITC Generate Lines (6En LInE), using the Set, Down, and Up switches.
- 2 Press Set again. The LED Time Code Display displays the current lines.
- 3 Use Down and Up to scroll parameters.
- 4 When you have chosen your desired option, press Set. The SYNC HD will retain the setting, even when the unit is powered off and on again, until it is changed.

Window Dub/Burn

By enabling this setting, you can superimpose a window dub onto an incoming video signal.



The front panel lets you enable window dub but does not let you adjust any window options.

To enable or disable the SYNC HD window dub from the front panel:

- 1 Select Burn Enabled (burn EnA), using the Set, Down, and Up switch.
- 2 Press Set again.
- 3 Use Down and Up to toggle between on/off.
- 4 Press Set. The SYNC HD will retain the setting, even when the unit is powered off and on again, until it is changed.

See “Generating a Window Dub” on page 57 for Pro Tools and the SYNC Setup software utility window dub instructions. See “SYNC HD Defaults” on page 67 for default display settings.

Freewheel Length/Duration

Freewheel Length sets the period of time for which the SYNC HD will continue to regenerate time code when incoming time code is interrupted.



See “Freewheel Duration” on page 44 for an explanation of this feature.

To set the freewheel duration:

- 1 Select Freewheel Length (FrEE LEn), using the Set, Down, and Up switches.
- 2 Press Set again. The LED Time Code Display displays the current setting, in frames.
- 3 Use Down and Up to scroll parameters.
- 4 Press Set.

LTC Output Level

Adjusts the audio level of the SYNC HD LTC output, from -24 dBu to +9 dBu.

LTC LEUL

See “Adjusting LTC Output Level” on page 39 for step-by-step LTC level instructions.

To set the LTC output level:

- 1 Select LTC Level (L7C LEUL), using the Set, Down, and Up switches.
- 2 Press the Set switch again. The LED Time Code Display shows the current setting, in dBu.
- 3 Use the Down and Up switches to switch between the parameter values.
- 4 Press Set.

Servo Gain

This setting provides a user selectable LTC servo gain offset. Selectable from the SYNC HD front panel and the Pro Tools Session Setup window, this parameter can significantly lessen or remove jitter on word clock while resolving to LTC (though it can slightly increase lockup time).

SErVo Gn


To set the LTC servo gain:

- 1 Select Servo Gain (SErVo Gn) using the Set, Down, and Up switches.
- 2 Press Set again. The LED Time Code Display shows the current setting (-001 is the default).
- 3 Use the Down and Up switches to display another parameter value. Servo gain provides four gain settings.
- 4 Press Set.

Pitch Memory/Hold

Pitch Memory is useful when resolving the SYNC HD to off-speed, free-running LTC. When Pitch Memory is enabled, the SYNC HD will remain at a pitch (sample rate) that corresponds to the last known clock reference speed.

PICH HLD

 Turn off Pitch Memory if you want to digitally transfer to another device and to ensure the receiving device gets the correct sample rate. Also, turn pitch memory off if you are doing an analog transfer to Pro Tools and want to ensure that the recording is made at the exact sample rate set by the session set up window.

To enable or disable the SYNC HD pitch memory feature:

- 1 Select Pitch Hold (PICH HLD), using the Set, Down, and Up switches.
- 2 Press Set again. The LED Time Code Display will display the current setting (on or off).
- 3 Use Down and Up to scroll parameters.
- 4 When you have chosen your desired option, press Set. The SYNC HD retains the setting, even when powered off, until it is changed.

Bi-Phase/Tach Pulses Per Frame

Bi-Phase/Tach involve several settings, including pulse per frame. This sets the number of Bi-Phase/Tach pulses per frame of time code.

To set the pulses per frame value for a Bi-Phase/Tach signal:

- 1 Select Bi-Phase/Tach Pulses Per Frame (bIPH PPF), using the Set, Down, and Up switches.
- 2 Press Set again. The LED Time Code Display shows the current parameter values, in pulses per frame.
- 3 Use Down Up to scroll parameters. Pressing and releasing the switches will change the value by just one pulse per frame. Pressing and holding the switches scrolls at a faster speed.
- 4 Press Set. The SYNC HD will retain the setting, even when the unit is powered off and on again, until it is changed.

Bi-Phase/Tach Input Signal

In addition to other Bi-Phase/Tach parameters, the Input Signal defines the *direction* of the Bi-Phase/Tach signal.

For complete instructions, see “Bi-Phase/Tach Signal” on page 47.

Video Format/System

Selects the format (NTSC or PAL) for both the incoming and outgoing video signals.

NTSC The standard for North and South America, Japan, and certain other parts of the world

PAL Used in most of Europe, Asia, and Africa. Users of SECAM video (for France, Russia, and other parts of the world) should select PAL.

Be sure you have selected the correct video format. The SYNC HD will not warn you if you have chosen the wrong one.

To select the desired video system:

- 1 Select Video System (VIDEo SY), using the Set, Down, and Up switches.
- 2 Press Set again. The LED Time Code Display will show one of the following:
 - NTSC (n75C)
 - PAL (PAL)
- 3 Use Down and Up to toggle parameters.
- 4 Press Set.

The SYNC HD will retain the setting, even when the unit is powered off and on again, until it is changed.

HD Video Format

Selects the video reference rate when the Clock Reference is set to Video Reference (HD).

Hd U IdEo

The following progressive video reference rates are available from the front panel display:

- Slow PAL 23.976
- Slow PAL 24
- 720p - 23.976
- 720p - 24
- 720p - 25
- 720p - 29.97
- 720p - 30
- 720p - 50
- 720p - 59.94
- 720p - 60
- 1080p - 23.976
- 1080p - 24
- 1080p - 25
- 1080p - 29.97
- 1080p - 30
- 1080i - 47.95
- 1080i - 48
- 1080i - 50
- 1080i - 59.94
- 1080i - 60
- 1080p - 50
- 1080p - 59.94
- 1080p - 60

MTC Idle Mute

MTC is output constantly whenever the SYNC HD is generating time code. Optionally, this output can be muted when time code (LTC) is idle.

IdLE TC

See “MTC Output and Idle Muting” on page 56.

Device ID


Toggles the device ID of the SYNC HD between SYNC HD (for use with Pro Tools 7.4 or higher) and SYNC I/O (for use with Pro Tools 7.3 or lower).

dEwI cE id

See “Configuring the Device ID” on page 13.

Using Fader Start

The SYNC HD provides six GPI outputs in total, two TTL-level and four relays. Together, this combination of outputs makes it possible for the SYNC HD to provide Fader Start capability.

 *Utilization of Fader Start has specific wiring requirements. See “GPI Relay Wiring for Fader-Start” on page 92.*

Fader Start allows faders in Pro Tools to trigger external devices to play and stop.

To implement Fader Start, Pro Tools maps the first two visible auxiliary input channels in a session to GPI Relay outputs 0 and 1 (first being left-to-right in the Mix window, top-to-bottom in the Edit window).

Example Fader Start Application

In a typical scenario, the Fader Start feature controls playback of a CD player. The CD player outputs are routed into a Pro Tools stereo Aux Input. As the Aux channel fader is moved above -120 dB, playback of the CD player is automatically triggered. Likewise, as the fader is moved below -120 dB, playback is automatically stopped.



To rearrange tracks, drag the Track Name left or right in the Mix window, or up or down in the Edit window. See the Pro Tools Reference Guide for more information.

To configure Pro Tools tracks for Fader Start Play and Stop:

1 Use the New Track dialog to create two new auxiliary input tracks. If you already have aux tracks, you will use the first and second (top-most in the Edit window, left-most in the Mix window).

2 When the first visible aux input in a Pro Tools session is above -120 dB, GPI Relay output 3 (Fader Start #1) will be enabled; otherwise, it will be disabled.

Similarly, when the second visible aux input in a Pro Tools session is above -120 dB, GPI Relay output #4 (Fader Start #2) will be enabled; otherwise, it will be disabled.

If you rearrange channel strips in the Pro Tools Mix or Edit windows, the two GPI outputs will update dynamically to reflect the current state. The Fader Start channel must be in a Show Track state (not hidden). See “GPI Relay Wiring for Fader-Start” on page 92 for additional GPI information.

Calibrating the SYNC HD Oscillator

The SYNC HD provides a feature for calibrating the frequency of the on-board crystal oscillator. This allows the SYNC HD to be used as an extremely accurate frequency reference while in Internal/VSO mode.

With normal usage, the SYNC HD should never require recalibrating. Each unit is factory calibrated to within ± 5 ppm (parts per million).

You may want to recalibrate the SYNC HD in the following situations:

- If greater than 5 ppm accuracy is required.
- If the unit needs to be matched to a unique (nonstandard) frequency.
- To precisely compensate for component aging.
 - and –
- To restore the original factory setting.



Oscillator recalibration does not occur during firmware updating or when resetting the SYNC HD to factory defaults (see “Restoring Factory Settings” on page 66).

Oscillator Resolution and Stability

SYNC HD calibration units are in $1/64$ th of a sample period. What this means is that the SYNC HD can theoretically be calibrated to about $1/3$ of a ppm. The unit will maintain calibration across a wide range in temperature. Long-term drift should be less than 1 ppm per year due to aging of the crystal. To put this in perspective, most digital audio products are accurate to within 20 to 50 ppm and drift with temperature. The SYNC HD’s accuracy is possible because it contains a low-jitter, high-stability temperature controlled crystal oscillator.


Warm Up the SYNC HD Before Recalibrating

Before you begin the calibration procedure, power on the SYNC HD and allow it to warm up for at least five minutes. The temperature of the room (or chassis) isn't critical during the calibration procedure. However, if you need better than 3 ppm accuracy, it is recommended that you allow the SYNC HD to warm up for at least 30 minutes and that the chassis be at normal operating temperature.

The original Oscillator Calibration value is printed on the factory sticker, on the SYNC HD bottom panel.

To restore the SYNC HD oscillator calibration to its factory setting:

- 1 Press Set, then press Up until Video System (VidEo SY) is displayed in the LED readout.
- 2 With the LED Time Code Display showing VidEo SY, press and hold the Up switch. While you continue to hold that switch, press the Clock Reference switch momentarily, and then release both switches. The LED Time Code Display will read:

The image shows a digital display with the text "OSC CAL" in a stylized, segmented font. The "O" and "S" are on the top line, and "C A L" are on the bottom line.
- 3 Press Set again. The LED Time Code Display shows the current parameter value, which shows a sample rate frequency deviation from -0999 to 0999.
- 4 Take note of the Oscillator Calibration value printed on the factory sticker, on the SYNC HD bottom panel.
- 5 Use the Down and Up switches to scroll through the parameter values.

6 When you reach a value that matches the sticker's value, stop scrolling and press Set. The LED Time Code Display will return to showing time code numbers. The SYNC HD is now properly calibrated.


The next time you press Set, the LED Time Code Display will again show O5C CAL. If you then press the Down switch, you'll disengage the Oscillator Calibration parameter name. To change the setting once again, you'll need to repeat steps 1 through 6.

Restoring Factory Settings

The SYNC HD can be reset to its default factory settings.

To reset all parameters to default settings:

- 1 Switch off power to the SYNC HD and wait at least 10 seconds.
- 2 Hold down the Up and Down front panel switches and turn on power to the SYNC HD. Do *not* release the Up and Down switches until the display reads FAC-CFG.

 *Resetting factory settings does not reset the SYNC HD oscillator. See "Calibrating the SYNC HD Oscillator" on page 65 for information.*

Factory Default Settings

The following table lists the default settings of each parameter.

SYNC HD Defaults

| Parameter Name | Default |
|-----------------------------|------------------------------------|
| Set Generator Start Time | 01:00:00:00 |
| Digital Reference | AES/EBU |
| Sample Freq (Rate) | 44.1 kHz |
| VITC Insertion | On |
| Pull Rates | Off |
| Base Clock | Session (1x Word) |
| (VITC) Reader Line | All |
| (VITC) Generate Line | 14–16 |
| Window Burn On/Off | On (Enabled) |
| Freewheel Duration | 8 frames |
| LTC Output level | +3 dBu |
| Servo gain | 0000 |
| Pitch Hold | Off |
| Bi-Phase Pulse-per-frame | 0100 |
| Bi-Phase Signal | A Lead B |
| Video System/Format | NTSC |
| Idle MTC Enabled | On |
| Window Burn options: | Enabled |
| | Size: Large |
| | Vertical Position: 20% from Bottom |
| | Horizontal Position: Center |
| | Color: White on Black background |
| Variable Speed Offset (VSO) | Off |

Managing and Selecting Video Inputs

(SD Video Rates Only)

The SYNC HD has two independent video inputs, “Video In” and “Video Ref In,” on the SYNC HD rear panel. These let you use one of the video inputs as a Clock Reference (the resolver sample clock master reference) and use the other input for working with VITC time code and the character generator (window dub).

If you have just a single video source, the SYNC HD provides a very simple method for connecting your single video source to both of the video inputs. See “Using Video Inputs with VITC and the Character Generator” on page 67.

In a typical video setup, you will supply a reference video signal (black burst or color bars) to your VCR and to the SYNC HD Video Ref input. You will then connect the VCR's video output to the SYNC HD Video In port. Finally, the SYNC HD Video Out will be fed to your picture monitor and/or another VCR.

Using Video Inputs with VITC and the Character Generator

Unlike selecting a video input to use for Clock Reference, input selection for VITC and character generator functions follows a simple rule. This rule is explained in the following sections and in Figure 1 on page 68.

Video Ref If the Clock Reference is one of the two video inputs, *and* the Positional Reference is Generate, then VITC and character generator functions are applied to the video arriving at the Video Ref input connector. This helps you avoid re-patching video cables whenever you want to stripe a videotape with your reference blackburst or color bars, along with internally generated time addresses for VITC (and/or LTC, and/or CG dub window). In Figure 1 on page 68, this scenario is identical to “Route A.”

Video In For all other combinations of Clock Reference and Positional Reference, VITC and character generator functions are applied to the video signal arriving at the Video In connector. In this way, the SYNC HD can read VITC from your videotape, or add VITC with or without character generation (window burn) while dubbing to a second VCR. In Figure 1 on page 68, this scenario is identical to “Route B.”




Figure 1. Video Input Flow diagram

Additional Synchronization Information

Video and VITC Signals

Black Burst and House Video Reference

A black burst signal is essentially a “position-less” video signal. As with any “shared” video signal, you’ll want to ensure that your video feed comes from a properly buffered and distributed source, such as a video distribution amplifier, or the house video reference/black burst output of another device in the chain.

Resolving to video instead of house video reference (black burst)

There are several reasons why you would resolve the SYNC HD to a video signal rather than house synchronization.

When House Video Reference is Unavailable Resolve to a video signal whenever you are synchronizing Pro Tools (or other device) to video, and you either:

- Do not have a house video reference.
 - or –
- Your setup includes equipment that lacks house video reference input and synchronization capability (including consumer grade VCR, or some entry-level computer-based editing systems).

Simple Setups In a modest setting with one or two VTRs, Pro Tools, and a SYNC HD, using the video signal as the clock reference is often satisfactory. In these situations, proper synchronization can be achieved using the video signal as clock reference.

Why VITC is Unavailable for Clock Reference

VITC itself does not provide clock information directly as part of its time code information, only positional information. However, since VITC is always embedded into a video signal, that video signal can be used as a clock reference by selecting Video Input as the clock reference (or Video Ref In if your facility has a house video reference).

VITC Timing Rule

The following rule is in effect whenever you are generating or regenerating VITC.

- ◆ Inserted VITC should be monotonic, regardless of whether it is being regenerated or generated.

By *monotonic*, it is meant that the VITC should be smoothly ascending or descending, with no repeated or skipped frame addresses. In order to achieve monotonicity, the external positional reference (while regenerating) or the clock source (in Generator Preset Mode) must be synchronous with the video signal onto which the VITC is being inserted.

Example of VITC Timing Rule

As an example, if you are using LTC as a positional reference from a 3/4-inch U-Matic VTR, then that VTR should be referenced to the same video signal that you are applying to the SYNC HD. As another example, in Generator Preset Mode (Positional Reference = Generate), a clock reference of Internal is not a good choice, simply because the SYNC HD internal crystal runs asynchronously with respect to the supplied video signal, and thus repeated or skipped frame addresses are sure to eventually occur.

LTC Signals

Because it's an analog audio signal, LTC can sometimes be susceptible to either tape dropouts (tape shedding), or to level mismatches between the LTC source and the LTC input. The SYNC HD freewheeling feature allows you to compensate for brief time code dropouts. However, if you have serious dropouts, you may not be able to sustain accurate synchronization.

If you plan to use LTC as a clock reference (whether or not you are also using it as a positional reference), you will need to ensure that your LTC is recorded at as high a level as possible without distortion, and that there are no dropouts longer than 1/80th of a frame.

The SYNC HD reads LTC most reliably when fed with a LTC signal of at least -12 dBu (and preferably 0 dBu to +3 dBu.)

LTC Servo Gain

You can adjust the servo gain of the SYNC HD LTC input from the SYNC HD front panel controls and from the Pro Tools Session Setup window. See "Servo Gain" on page 62 for more information.

Working with Analog Machines

It is good practice on a 24-track analog tape machine to record time code on Track 24 at a reference level of -10 dBu (or lower), with Track 23 left blank as a "guard" track. This practice avoids crosstalk "bleed" that can occur between the time code track and otherwise adjacent audio tracks. Time code (which is a mid-frequency alternating pitch square wave) is very sensitive to crosstalk from adjacent tracks, and conversely you don't want audible time code leaking onto your audio tracks.

If your ATR is under the control of a synchronizer, you must make sure that the synchronizer and the SYNC HD are both locked to the same reference source (such as, typically, from a video black burst generator.)

Auto-Switch LTC/VITC

Auto-Switch LTC/VITC lets the SYNC HD automatically select between these two (time code) sources.

LTC and VITC both provide useful and unique capabilities. For instance, it is impossible to read LTC off a paused videotape. Consequently, using only LTC, there's no way you can use Pro Tools to perform Auto-Spotting of regions when the tape is paused. However, VITC continues to be read as long as the picture remains visible, so it *can* be used as a positional reference when the VTR is paused. On the other hand, VITC cannot be read at fast winding speeds (except by broadcast-quality VTRs); LTC can be read at fast winding speeds, as long as its signal remains within the high-end frequency response of the ATR or VTR.

Examples of Auto-Switch LTC/VITC

- ◆ The SYNC HD will switch to LTC for positional reference during hi-speed searching and cueing, for example, or whenever the tape speed is too high to read VITC.
- ◆ The SYNC HD will switch to VITC if LTC stops or is unavailable. This will include, for example, if a tape is paused or parked.
- ◆ If both LTC and VITC are available, the SYNC HD chooses which one to use based on the speed of playback. The switch-over point is approximately 75% of full 1x playback speed. Above 75% playback speed, LTC is favored; below 75% speed, VITC is favored.

If a dropout occurs, the SYNC HD waits until the freewheel duration has expired before attempting to switch over to the opposite source. If neither source is available, the SYNC HD will stop reading time code.

Digital Clock Signal Types

A reference clock signal is part of any digital recording system. It is required because whenever digital audio information is mixed together or passed between devices, the playback samples must be aligned with the recording samples. In some cases (such as with AES/EBU or S/PDIF digital interfaces), the clock signal is embedded in the data stream itself. In other cases, such as SDIF, the clock signal is carried as an entirely separate signal from the digital audio sample data.

The SYNC HD is able to resolve to AES/EBU and Word Clock.

AES/EBU

Some professional digital audio products use AES/EBU “null clock” (which is an AES/EBU data stream that contains only clock information only and no audio information) as a system clock reference source. These systems rely upon a single AES/EBU master clock source that is distributed throughout a digital audio facility, in much the same way that house synchronization is distributed throughout a video facility. If you are connecting the SYNC HD to such a system, you will want to use the SYNC HD AES/EBU input as the clock reference connection, so that all system components are referenced to the same time base. (Note that AES/EBU does not support 176.4 kHz and 192 kHz sample rates.)

In some cases (such as using the SYNC HD as a standalone clock resolver or time code generator without a digital audio workstation), you may wish to use an audio DAT machine (or other similar device) as a source of AES/EBU null clock, and resolve your system to this reference source. In this case, the audio sample data in the AES/EBU data stream is stripped off, and only the clock information is used.

Word Clock

Many professional digital audio products—including open-reel multitrack tape recorders, digital mixing consoles, and the Tascam DA-88 modular digital multitrack—have Word Clock (1x sample rate) connectors.

Word Clock allows the DA-88 (and other Word Clock-compatible devices) to send or receive external clock information which controls the sample rate, which in turn (where applicable) controls the play and record speed.

Using just Word Clock, it is possible to create a “chain” of digital devices in your studio by picking one source as the Word Clock master, and configuring other sources as Word Clock slaves.

Bi-Phase/Tach

Bi-Phase and Tach are used with mag machine, 16, 35, and 70 mm projectors, flatbed editing systems and other types of motor-driven film equipment. Bi-Phase (sometimes called Quadrature Sync) and Tach information are similar, though they do differ.

Bi-Phase A Bi-Phase signal consists of two square waves, which are generated directly by a device’s transport mechanism, and which are 90° out-of-phase with one another. As a Bi-Phase-generating device plays it outputs a steady stream of square waves that the SYNC HD can use as its clock reference, at nearly any speed including still/paused.

The SYNC HD uses the phase relationship between the two square waves to determine the device’s direction (forward or reverse). However, this is relevant only when the SYNC HD is using the Bi-Phase signal as a positional reference.

Tach A Tach signal is a variation of Bi-Phase. With Tach’s two signals, one is used only as the direction indicator, while the other is used as the velocity, or rate indicator. The SYNC HD uses this rate signal when resolving to Tach as a clock reference.

There are several different standards for the number of pulses-per-frame for Bi-Phase or Tach devices. You can set the SYNC HD to match the PPF rate of the external device’s Bi-Phase/Tach encoder from Pro Tools, or using the SYNC Setup software utility’s Pulse Per Frame setting (Windows only).

Strictly speaking, Bi-Phase/Tach signals are clock reference signals, and do not contain positional information of their own. However, they do contain enough information for the SYNC HD to calculate positional information.

Bi-Phase/Tach signals use two square waves to generate pulses that can function as a clock reference. The two square waves are 90° out-of-phase, in a pattern that resembles this:




Illustration of Bi-Phase/Tach signals

With a Bi-Phase signal, the SYNC HD can deduce the direction (forward or reverse) of the signal based upon which wave is read “high” relative to the other. For instance, with some film equipment, when the device is running forward, it will generate a Bi-Phase signal where the “A” wave leads the “B” wave—that is, where the A wave peaks before the B wave peaks. When the device is in reverse, the B wave will lead the A wave.

However, some film equipment works in the opposite manner, which is why the SYNC HD Input Signals option lets you make the appropriate selection (Fwd = A leads B, or Fwd = B leads A).

Calculating the direction of a Tach signal is slightly different. As you may recall, Tach also uses two signals. The “A” signal is a square wave that provides clock information; the “B” signal is in a steady state (high or low) that indicates the direction. Unfortunately, not all Tach-generating equipment uses the B signal in the same way. Fortunately, the SYNC HD Input Signals options allows you to choose the appropriate method (Tach: Fwd = B is Low, or Tach: Fwd = B is High).

This explains how the SYNC HD can use a Bi-Phase/Tach signal to deduce the direction, and how it also uses the signal as a clock reference—as long as the SYNC HD is told the starting frame of the first clock signal.

Pilot Tone

The SYNC HD can resolve to an external Pilot Tone signal for synchronizing to (or transferring audio from) certain types of open-reel audio tape recorders.

In general, Pilot Tone is a sine wave reference signal running at the “line frequency” or “mains frequency,” meaning the same frequency transmitted by the AC line voltage from the local power utility.

Pilot Tone is used on location film shoots to establish a common synchronization reference between a film or video camera with a portable 1/4-inch analog ATR (such as those made by Nagra or Stellavox). On location, Pilot Tone is derived by clock referencing the camera to the local AC line frequency (which is 60 Hz or 50 Hz depending on the country of origin), and this same frequency is then used to clock-reference the ATR. The result is that both the camera and the ATR will run at the same speed.

You can think of Pilot Tone as a kind of inexpensive and readily available “house sync” for location production. Increasingly, it’s being replaced by time code, since new-generation film cameras as well as many portable DAT recorders are time code-capable.

Please note that Pilot Tone contains no positional information; it is simply a clock reference. Most 1/4-inch machines have a center track for time code or pilot.

appendix b

Technical Specifications

General

| Nominal Sample Rates | | | | | | |
|-----------------------|-------------|-------|-------|--------|--------|--------|
| Pull Up/Down | Sample Rate | | | | | |
| | 44100 | 48000 | 88200 | 96000 | 176400 | 192000 |
| +4.1667% and +0.1% | 45983 | 50050 | 91967 | 100100 | n/a | n/a |
| +4.1667% | 45938 | 50000 | 91875 | 100000 | n/a | n/a |
| +4.1667% and -0.1% | 45892 | 49950 | 91783 | 99900 | n/a | n/a |
| +0.1% | 44144 | 48048 | 88288 | 96096 | 176576 | 192192 |
| -0.1% | 44056 | 47952 | 88112 | 95904 | 176224 | 191808 |
| -4.0% and +0.1% | 42378 | 46126 | 84757 | 92252 | n/a | n/a |
| -4.0% | 42336 | 46080 | 84672 | 92160 | n/a | n/a |
| -4.0% and -0.1% | 42294 | 46034 | 84587 | 92068 | n/a | n/a |

General

| | | |
|--------------------------------|---|---|
| Frame Rates | 30 fps | |
| | 30 fps drop-frame | |
| | 29.97 fps | |
| | 29.97 fps drop-frame | |
| | 25 fps | |
| | 24 fps | |
| | 23.976 fps | |
| Variable Speed Override | ±699 cents (±58.25%) | |
| | Aging: | ±2 ppm/year typical |
| | | |
| Burn-in Window | Position: | 5 horizontal and vertical positions |
| | Size: | Large and small text |
| | Color: | Black or white text on white or black background or keyed |
| | | |
| Dimensions | Height: | 1RU/1.75" (4.45 cm) |
| | Width: | 19.0" (48.26 cm) |
| | Depth: | 10.5" (26.67 cm) |
| | | |
| Weight | 5.0 lbs (2.27 kg) | |
| | | |
| Vibration Resistance | 5 mm displacement, 10 to 55 Hz, each axis | |

General

| | | |
|------------------------------|--|--|
| Shock | 5 G max | |
| | | |
| Operating Temperature | 32 to 131 degrees F (0 to 55 degrees C) | |
| | | |
| Storage Temperature | -40 to 176 degrees F (-40 to 80 degrees C) | |
| | | |
| Relative Humidity | 0 to 95%, non-condensing | |
| | | |
| Power Requirements | Voltage: | 85 to 264 VAC |
| | Frequency: | 47 to 63 Hz autoswitching |
| | Wattage: | 9.5 W typical, 30 W maximum |
| | Connector: | 3-pin, AC and ground (IEC 950:320;3.2.4) |
| | | |
| Agency Compliance | Meets FCC Part 15 Class A limits, CD EN 55022A, CE EN 60950, CE EN 55081:1, UL 1419 and CSA 22.2 | |

Rear Panel Connectors

| Connector | Specifications | |
|------------------------|---------------------------|--|
| LTC In | Format: | SMPTE/EBU 80-bit longitudinal, drop frame/non-drop frame |
| | Connector: | 3-pin XLR female per IEC 268-12 |
| | Speed Range: | 1/30 to 80X play speed, forward or backward |
| | Level: | -24 dBu to +9 dBu, differential (pin 2 hot) |
| | Impedance: | 200K ohms |
| | | |
| LTC Out | Format: | SMPTE/EBU 80-bit longitudinal, drop frame/non-drop frame |
| | Connector: | 3-pin XLR male per IEC 268-12 |
| | Speed Range: | ±10% of play speed |
| | Level: | -24 dBu thru +9 dBu RMS, differential (pin 2 hot) |
| | Level Default: | 0 dBu RMS, 1.52V p-p ±10mV |
| | Output Impedance: | 5K ohms |
| | Load Impedance (minimum): | 100 ohms |
| | Rise/Fall Time: | 42us ± 1us measured between 10% and 90% p-p |
| | S/N Ratio: | -60 dB RMS at 0 dBu level |
| | | |
| Video (Main) In | Format | NTSC or PAL composite video |
| | Level: | 1V p-p |
| | Termination: | 75 ohms |

Rear Panel Connectors

| Connector | Specifications | |
|-------------------------|-------------------|---|
| Video (Main) Out | Level: | 1V p-p |
| | Source Impedance: | 75 ohms |
| | | |
| (VITC In) | Format | SMPTE 90-bit, drop frame/non-drop frame |
| | Line Range: | 10 to 40 (all-line mode), 10 to 22 (single-line mode) |
| | | |
| (VITC Out) | Format: | SMPTE 90-bit, drop frame/non-drop frame |
| | Line Range: | Two lines, 10 to 20 |
| | | |
| Video (Ref) In | Format: | NTSC or PAL composite video |
| | Level: | 1V p-p |
| | Termination: | 100K ohms |
| | | |
| Video (Ref) Out | Level: | 1V p-p |
| | Termination: | 100K ohms |
| | Description: | Passive loop-thru of Video Ref in |
| | | |
| AES/EBU In | Level: | 5 V p-p at 110 ohms (pin 2 hot) |
| | Connector: | 3-pin XLR female per IEC 268-12 |
| | | |
| AES/EBU Out | Level: | 5 V p-p at 110 ohms (pin 2 hot) |
| | Connector: | 3-pin XLR male per IEC 268-12 |

Rear Panel Connectors

| Connector | Specifications | |
|-------------------------------------|----------------------|---|
| Word Clock In | Level: | 0 to .5 V (low), 2.0 to 6.0 V (high) |
| | Connector: | BNC Female |
| | | |
| Word Clock Out | Level: | TTL (3.3 V typical) |
| | Connector: | BNC Female |
| Loop Sync In | Level | 0 to .5 V (low), 2.0 to 6.0 V (high) |
| | Connector | BNC Female |
| | | |
| Loop Sync Out | Level | TTL (3.3 V typical) |
| | Connector | BNC Female |
| | | |
| Bi-phase/Tach/ GPI/Pilot | Connector: | 25-pin D-subminiature female (DB25) |
| | | |
| | | |
| (Bi-phase/Tach In) | Frequency Range: | 0 to 76.8 KHz |
| | Level: | 4.5 to 12V, opto-isolated |
| | Current: | 10 mA max |
| | Polarity (bi-phase): | Both inputs are software programmable |
| | Polarity (tach): | "Direction" polarity is software programmable |
| | Modulo Range: | 2 thru 254 |

Rear Panel Connectors

| Connector | Specifications | |
|------------------------|-------------------------|--|
| (Pilot In) | Level: | 100 mV to 5.5 V p-p, differential |
| | Frequency Range: | 50/60 Hz nominal |
| | Impedance: | 200K ohms |
| | | |
| (GPI In) | Description: | Four opto-isolator inputs/returns |
| | Level: | 4.5 to 5.5 V |
| | Current: | 10 mA max |
| | Frequency: | Frame-rate max |
| | Latency: | Half frame max |
| | | |
| (GPI Out (TTL)) | Description: | Two TTL-level outputs |
| | Level: | TTL (3.3 V typical) |
| | Current: | 15 mA |
| | Frequency: | Frame-rate max |
| | Latency: | Half-frame max |
| | | |
| (GPI (Relay)) | Description: | Four pairs of SPST contacts, normally open |
| | Load (while switching): | .5 A max at 200 VDC |
| | Load (continuous): | 1.5 A max at 200 VDC |
| | Operate/Release Time: | 1 ms |
| | Repetition Rate: | Frame-rate max |
| | Latency: | Half frame max |

Rear Panel Connectors

| Connector | Specifications | |
|---------------------------------|-----------------|--|
| MIDI Time Code (MTC) Out | Current Rating: | 15 mA current loop |
| | Rate: | 31.25 Kilobaud |
| | Connector: | 5-pin DIN female |
| | Cable Length: | 50 feet (15 meters) max |
| | | |
| Host Serial | Format: | Apple Mac-compatible serial printer port |
| | Connector: | 8-pin mini DIN female |
| | Cable Length: | 50 feet (15 meters) max |

appendix c


Wiring Diagrams and Pin Assignments

LTC Connectors

The SYNC HD LTC In and LTC Out connectors are balanced XLRs with Pin 2 wired “+” or “hot,” Pin 3 wired “-” or “cold,” and Pin 1 wired to ground (shield). Depending on whether you are connecting a balanced or unbalanced signal to these connectors, different wiring configurations are recommended for optimum signal integrity, especially for long cable runs.

If you are connecting a balanced signal to the SYNC HD LTC In or LTC Out connectors:


- Pin 1 and ground should be connected at the input only (not at the output). This will prevent ground loops between the shield and the Pin 1 conductor.



Wiring diagrams for the SYNC HD LTC In and LTC Out connectors (balanced signal)



If you are connecting an unbalanced signal to the SYNC HD LTC In or LTC Out connectors:

- Connect only Pin 2 to the “+” signal;
- Connect Pin 1 to ground at all inputs and outputs.




Wiring diagrams for the SYNC HD LTC In and LTC Out connectors (unbalanced signal)

Bi-Phase/GPI/Pilot Pin Diagram







Bi-Phase/GPI/Pilot

Bi-phase/Tach OptoCoupler Input




Bi-phase/Tach

GPI Relay Outputs




GPI Relay Output

GPI (TTL)/MTC Outputs



GPI TTL/MTC Output

GPI (opto) Inputs



GPI (opto) Input

Connector Pin Assignments

Mac Serial Port Connector Pin Assignments

| Mac Serial Port | | | |
|-----------------|---------|--|----------------------|
| Pin # | Name | Description | Mac Connection |
| 1 | NC | No connection | Pin 2 (HSKiB) |
| 2 | RTS_IN | Request To Send (input to SYNC HD) | Pin 1 (HSKoB) |
| 3 | RX_OUT | Transmitted data (output from SYNC HD) | Pin 5 input (RXDB-) |
| 4 | GND | Chassis ground | Ground |
| 5 | TX_IN | Received data (input to SYNC HD) | Pin 3 output (TXDB-) |
| 6 | GND | Chassis ground | Pin 8 input (RXDB+) |
| 7 | CTS_OUT | Clear To Send (output from SYNC HD) | Pin 7 input (GPiB) |
| 8 | NC | No connection | Pin 6 (TXDB+) |
| Shell | GND | Chassis ground | Ground |

Bi-phase/Tach/GPI/Pilot Port (Accessory Port) Connector Pin Assignments

| Pin # | Name | Description |
|-------|-----------|--|
| 1 | GPOUT0 | GPI TTL-level output 0 |
| 2 | GPOUT1 | GPI TTL-level output 1 |
| 3 | GPOUT0_A | GPI Relay 0, contact A |
| 4 | GPOUT0_B | GPI Relay 0, contact B |
| 5 | GPOUT1_A | GPI Relay 1, contact A |
| 6 | GPOUT1_B | GPI Relay 1, contact B |
| 7 | GPOUT2_A | GPI Relay 2, contact A |
| 8 | GPOUT2_B | GPI Relay 2, contact B |
| 9 | GPOUT3_A | GPI Relay 3, contact A |
| 10 | GPOUT3_B | GPI Relay 3, contact B |
| 11 | OPTRETURN | Return from Bi-phase/Tach opto-isolators |
| 12 | BIPHB_I | Input to Bi-phase/Tach opto-isolator B |
| 13 | BIPHA_I | Input to Bi-phase/Tach opto-isolator A |
| 14 | GND | Chassis ground |
| 15 | PILOT_IN- | Pilot tone input, negative |
| 16 | PILOT_IN+ | Pilot tone input, positive |
| 17 | RET0 | Return from GPI opto-isolator "0" |
| 18 | GPIN0 | Input to GPI opto-isolator "0" |
| 19 | RET1 | Return from GPI opto-isolator "1" |
| 20 | GPIN1 | Input to GPI opto-isolator "1" |
| 21 | RET2 | Return from GPI opto-isolator "2" |
| 22 | GPIN2 | Input to GPI opto-isolator "2" |
| 23 | RET3 | Return from GPI opto-isolator "3" |
| 24 | GPIN3 | Input to GPI opto-isolator "3" |
| 25 | VDD | +12V DC |
| Shell | GND | Connected to chassis ground |

SYNC HD Cable Pin Assignments

SYNC HD DigiSerial Cable

A 12-foot Serial cable is included with the SYNC HD to support connection of the SYNC HD to the DigiSerial port on a Pro Tools|HD-series core card.

If you need to make a custom DigiSerial cable, refer to the following pin assignment table for the SYNC HD-to-DigiSerial port cable.

SYNC HD to DigiSerial cable

| Mini DIN 8-pin Male to Mini DIN 8-pin Male | |
|--|---|
| 1 | 2 |
| 2 | 1 |
| 3 | 5 |
| 4 | 4 |
| 5 | 3 |
| 6 | 8 |
| 7 | 7 |
| 8 | 6 |

SYNC Setup Software Utility Cable (Windows Only)

The following table shows the pin assignments needed for a SYNC HD-to-COM port cable to support the SYNC Setup software utility on a Windows computer.

SYNC HD to COM cable (Windows)

| Mini DIN 8-pin Male to 9-pin D-Sub Female | |
|---|-----------------|
| 2 | 7 |
| 3 | 2 |
| 4 | 5 |
| 5 | 3 |
| 7 | 8 |
| Shell | Shell |
| 1, 6, 8 none | 1, 4, 6, 9 none |

Bi-phase/Tach/GPI/Pilot Port Interfacing Notes

- ◆ The six opto-isolators are 6N137 devices. The four GPI input ports pass through 390 ohm series resistors to the cathode. The two Bi-Phase/Tach inputs pass through 634 ohm series resistors to the cathode.
- ◆ The two TTL-level GPI outputs are driven by a 74FCT541. Each output passes through a 220 ohm series resistor.
- ◆ 12 volts is supplied at the connector for the purpose of driving the opto-isolators in film tach applications. It is regulated and can supply up to 100mA.
- ◆ For Tach, the “rate” input is “BIPHA_I” and the “direction” input is “BIPHB_I.” The polarity of “BIPHB_I” is software programmable and defaults to “low” for “forward.”
- ◆ For Bi-phase, the default polarity relationship between A and B is software programmable. The default setting for “forward” is “A leads B.” This means that the rising edge of A (0° phase) must precede the rising edge of B (90° phase).
- ◆ For highest signal quality, use a 25-pin cable with individually shielded conductors.

GPI Relay Wiring for Fader-Start

The SYNC HD provides a total of four Relay-level GPI outputs on pins 3/4, 3-10 of the DB25 connector (see the circuit diagram GPI (TTL)/MTC Outputs).

The GPI Relay outputs are intended to drive Relay loads only.

GPI Triggers

GPI output signals information:

- 0 (relay) = Play
- 1 (relay) = Record Ready
- 2 (relay) = fader start #1
- 3 (relay) = fader start #2
- 4 (TTL) = Stop
- 5 (TTL) = Record

Logical GPI numbers 0 through 3 are associated with GPI relay outputs 0 through 3 (pins 3 through 10). GPI numbers 4 and 5 are associated with GPI TTL outputs 0 and 1 (pins 1 and 2).

GPI TTL Wiring

The circuit can drive approximately 2 mA through a load of 1.6K and maintain a logic high level of 3.3V. In an application where the equipment being controlled has more demanding power requirements, an external buffer or relay circuit must be used. This would typically be constructed as part of a custom electrical interface.

Each GPI TTL output is fully short-circuit protected via a 220-ohm series resistor.

Before attempting to wire any type of custom interface, always check the electrical specifications provided by the equipment manufacturer, including voltage levels, current, loading and polarity. Incorrect wiring may damage your equipment, the SYNC HD, or cause personal injury.

index

Numerics

- 9-pin 21
 - MachineControl serial time code 36
 - output ports 28

A

- absolute time code (and LTC) 43
- AC Power In 28
- AES/EBU
 - as clock reference 37
 - connecting 11
 - connectors 27
- Auto ID 14
- Auto Switch 45
 - and freewheel duration 71

B

- back panel 26
- base clock 60
- Bi-Phase/Tach 26, 46, 72
 - for mag, flatbed, projectors 40
 - front panel 63
 - GPI Relay Outputs diagram 86
 - GPI/Pilot pin assignments 90
 - input wiring diagram 84, 85
 - positional reference 46
 - SYNC Setup software utility 31
- black burst (house video reference) 10, 26, 36
- BNC 38
 - back panel 26

C

- character generation
 - see window dub
- clock reference 15, 71
 - and clock source 15
 - choosing digital source 37
 - front panel 23
 - LEDs 23
 - list of supported clock sources 2
 - SYNC Setup software utility 29
- Clock Source 15
- color (for window dub) 57

D

- DASH 38
- DAT signals 71
- DF (drop frame) front panel LED 25
- digital clock
 - AES/EBU, Word, SuperClock 71
 - front panel 60
 - setting 37
- Down switch 35
- drop outs
 - and auto-switch LTC/VITC 71
 - and time code freewheel 44
 - LTC troubleshooting 70

E

- external clock out 60

F

- factory defaults 66
- fader start 64
 - wiring 92
- fields (odd/even) indication 29
- flatbed and Bi-Phase/Tach 40
- fps 29
- frame rate
 - front panel 25
 - SYNC Setup software utility 29
- freewheel duration 30
 - and auto-switch LTC/VITC 71
 - front panel 61
- front panel
 - Lockout mode 33
 - switches and displays 23

G

- generate
 - time code gen/regen 49
- Generator
 - Bi-phase Preset 31
 - controls for 35
 - Preset Mode 50
 - Reference Rule 50
- Generator/Parameter Controls 35
- GPI
 - and fader start 64
 - back panel connector 26
 - pinout 84
 - TTL wiring 92
- GPI (opto) Inputs 87

H

- Host Serial 26
- house sync 10

I

- Idle MTC Enabled
 - front panel 56
 - in SYNC I/O Setup 56
- internal clock 41

L

- LED Time Code Display 24
- legacy interfaces 9
- Locked indicator
 - front panel 25
 - Pro Tools 17
- Loop Master 23
- Loop Sync 14, 28
 - Auto ID 14
 - connecting 8
- LTC 10
 - and clock reference 38
 - generation/regeneration 52
 - In (back panel) 27
 - lockup speed settings 39
 - Out (back panel) 27
 - output level (front panel) 62
 - output level (Pro Tools) 39
 - output level (SYNC Setup software utility) 30
 - positional reference 43
 - servo gain 62
 - wiring diagrams 83

M

- Mac Serial Port
 - pinout 89
- MachineControl 21
- mag and Bi-phase/Tach 72
- monotonic VITC 69
- MTC 56
 - and Idle MTC Output 30
 - burst mode 56
 - generation/regeneration 56
 - Out (back panel) 27
 - pinout 87
 - time code output 27
- MTC Out 12

N

NTSC 30
 selecting 63
null clock 71

O

oscillator reset 65

P

PAL 30
 selecting 63
phase
 see Bi-Phase
Pilot
 back panel port 26
 pinout 84
 Tone 40
Pin 1, 2, 3 (LTC) 83
Pitch Memory 43
 enabled (SYNC I/O Setup) 30
 front panel (pitch hold) 62
positional reference 17, 43
 front panel 25
 SYNC Setup software utility 29
Pull Rate 29
Pull Up and Pull Down
 actual rates 24
 when generating time code 49
Pulses Per Frame
 configuring 40, 41
 front panel 63

Q

Quadrature Sync 72

R

Read/Regeneration Mode 49
regenerating time code 49
relays 64
Remote Mode
 front panel 25
 SYNC Setup software utility 33
Remote-Only Mode 33
RUN/STOP/CLEAR 35

S

sample rate 17
 and pull up/down rates 24
 front panel (sample frequency) 60
 front panel LED displays 24
SECAM 30, 63
serial port 26
serial time code
 and clock reference 36
 using for positional reference 46
Servo Gain 62
Slave Clock
 see SuperClock
Speed Cal Indicator
 front panel 25
 Pro Tools 17
Status
 front panel 25
 SYNC Setup software utility 29
Super Clock 38
 as clock reference 37
 SYNC Setup software utility 29
SYNC Setup software utility
 configuring 21
 overview 28
 status display 29
 time code display 29
 wiring diagram 91

T

- Tach 72
 - connector 26
- time code
 - drop outs, freewheeling 44
 - generating/regenerating 49
 - MIDI (MTC output) 27
 - serial 36
 - SYNC Setup software utility 29
- Time Code Rate 18
- TTL 87
 - wiring 92

U

- Up switch 35
- user sync
 - see base clock

V

- Variable Speed Override (VSO) 31, 42
- Vertical Position 57
- video
 - connecting 10
 - format, front panel 63
 - format, SYNC Setup software utility 30
 - managing inputs 67
 - odd/even field, display of 29
- Video In connector 27
- Video In format 20
- Video Out connector 27
- Video Ref
 - connecting 10, 26
 - terminating 26
- Video Ref format 18

VITC

- as positional reference 53
 - connector for positional reference 27
 - default line pair 54
 - Generate Lines, front panel 61
 - Generate Lines, SYNC Setup software utility 30
 - Insertion, front panel 60
 - Insertion, SYNC Setup software utility 30
 - monotonic 69
 - positional reference 44
 - Read Lines, defaults 30
 - Read Lines, front panel 60
 - Read Lines, SYNC Setup software utility 30
 - related settings 45
 - timing rule 69
 - video source rule 53
- VSO (Variable Speed Override) 31

W

- window dub
 - front panel enable 61
 - generating 57
 - setting color 57
 - vertical position 57
- wiring diagrams 83
 - SYNC Setup software utility 91
- Word clock 71
 - 1x clock 38
 - as clock reference 37
 - base clock output 60
 - connecting 11
 - connectors 28



www.digidesign.com

DIGIDESIGN

2001 Junipero Serra Boulevard
Daly City, CA 94014-3886 USA
Tel: 650.731.6300
Fax: 650.731.6399

TECHNICAL SUPPORT (USA)

Tel: 650.731.6100
Fax: 650.731.6384

PRODUCT INFORMATION (USA)

Tel: 800.333.2137

INTERNATIONAL OFFICES

Visit the Digidesign website
for contact information