

VENUE Plug-In Installers

Creating VENUE Plug-In Installation CDs or USB Key Disks

To install a plug-in from a CD image onto your VENUE system, you must first burn the installer to a CD or copy the installer to a USB key disk.

The CD or USB key disk can then be inserted into your VENUE system to install the plug-in.

To burn or copy the Plug-In Installer to a CD or USB key disk:

- 1 Download the plug-ins CD image file.
- 2 Unzip the file.
- 3 In the plug-in's CD image folder, locate the TDM Plug-Ins folder.

▲ *If the TDM Plug-Ins folder is not on the root level of the CD (or USB key disk), the VENUE system will not be able to install the plug-in.*

- 4 Burn the TDM Plug-Ins folder to the root level of a CD or USB key disk.

▲ *A plug-in's CD Image folder may also include a User Guide, Read Me, and manual Setup.exe installer. User Guide and Read Me PDF files must be viewed on a system other than VENUE that supports Adobe Acrobat Reader.*